



ASSEMBLY INSTRUCTIONS *COASTER FINE FURNITURE*



Fine Furniture for every stage of life

115601(B1&B2) **Dining Table**

ITEM: 115601(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1(BOX 1)

A	TOP		1PC
B	MOUNTING PLATE		4PCS
C	LEAF		1PC
D	CROSSBAR		2PCS

B2(BOX 2)

E	LEG		4PCS
---	-----	--	------

HARDWARE IDENTIFICATION

Z-B1(BOX 1) - HARDWARE PACK IS LOCATED IN 115601(B1)

1	LONG BOLT (Ø5/16" x 60mm - BLK)		8PCS
2	SHORT BOLT (Ø5/16" x 32mm - BLK)		12PCS
3	LOCK WASHER (Ø5/16" x 2mm - BLK)		20PCS
4	FLAT WASHER (Ø5/16" x 2mm - BLK)		20PCS
5	ALLEN WRENCH (4mm x 35 x 57mm - BLK)		1PC
6	FLAT HEAD SCREW (#8 x 30mm - BLK)		16PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 115601(B1&B2)


ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2




STEP 3

3.1



3.2




ITEM: 115601(B1&B2)


ASSEMBLY INSTRUCTIONS



STEP 4




STEP 5 COMPLETE



ADJUSTABLE LEVELER



ITEM: **115601(B1&B2)**



Note: Dimension tolerance $\pm 5\%$