



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

115602MOS
Side Chair

ITEM: 115602MOS

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME		1PC
B	SEAT CUSHION WITH FRAME		1PC
C	LEG		2PCS

HARDWARE IDENTIFICATION

1	LONG BOLT (Ø1/4" x 82mm - RBW)		4PCS
2	MEDIUM BOLT (Ø1/4" x 60mm - RBW)		4PCS
3	SHORT BOLT (Ø1/4" x 38mm - RBW)		3PCS
4	LOCK WASHER (Ø1/4" x 2mm - RBW)		11PCS
5	FLAT WASHER (Ø1/4" x 2mm - RBW)		11PCS
6	ALLEN WRENCH (4mm x 57mm - RBW)		1PC

NOTE:


Quantity shown as for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 115602MOS

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




STEP 3

COMPLETE



ITEM:115602MOS



Note: Dimension tolerance $\pm 5\%$