

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

121231(B1&B2) *Dining Table*

REVISION 0 : 05/30/2018 REVISION 1 : 09/04/2018 REVISION 2 : 07/01/2020 REVISION 3 : 10/16/2025

ITEM:121231(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

AN TOP



1PC

DN BASE



2PCS

BN LEAF



2PCS

EN CROSSBAR



1PC

CN MOUNTING PLATE



2PCS

B2 (BOX 2)

FN PEDESTAL COLUMN



2PCS

HARDWARE IDENTIFICATION

Z-B1(BOX 1) - HARDWARE PACK IS LOCATED IN 121231(B1)

- 1 LONG BOLT (5/16" x 45mm BLK)
- 0

12PCS

5 FLAT WASHER (5/16" x 22D x 2mm - BLK)



28PCS

- 2 SHORT BOLT (5/16" x 38mm BLK)
- 8PCS

6

ALLEN WRENCH (4mm - BLK)



1PC

- 3 HEX NUT (5/16" x 12mm - BLK)
- 8PCS
- 7 WRENCH (12mm BLK)



1PC


- 4 LOCK WASHER (5/16" x 12D x 1.1mm - BLK)
- **28PCS**


ITEM: 121231(B1&B2)

COASTER

ASSEMBLY INSTRUCTIONS

STEP 1






ITEM:121231(B1&B2)


COASTER

ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4




ASSEMBLY INSTRUCTIONS STEP 5



ITEM:121231(B1&B2)





Note: Dimension tolerance ±5%

COASTERFURNITURE.COM