

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108482 Side Chair

REVISION 0: 01/03/2024 REVISION 1: 11/12/2025

PAGE 1 OF 6

COASTERFURNITURE.COM



#### **ASSEMBLY INSTRUCTIONS**


#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

#### PARTS IDENTIFICATION

A	BACK FRAME		1PC
В	FRONT LEG FRAME		1PC
С	LEFT SIDE RAIL		1PC
D	RIGHT SIDE RAIL		1PC
E	LEFT STRETCHER		1PC
F	RIGHT STRETCHER	(===)	1PC
G	SUPPORT BAR		2PCS
н	SEAT CUSHION		1PC

#### NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

#### HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M5 x 100MM - BLK)		1PC
2	BOLT (M8 x 50MM - BLK)		4PCS
3	LOCK WASHER (5/16" - BLK)		4PCS
4	LONG PAN HEAD SCREW (#8 x 1 1/2" - BLK)	<b>⊕)</b> <i>mmmm</i> >	4PCS
5	SHORT PAN HEAD SCREW (#8 x 1 1/4" - BLK)		4PCS
6	L BRACKET (ZY 447 - BLK)		3PCS
7	FLAT HEAD SCREW (M3.5 x 16MM- RBW)	<b>4000(\$</b> )	6PCS

#### NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.


# COASTER

#### **ASSEMBLY INSTRUCTIONS**

## STEP 1




## STEP 2




# COASTER

#### **ASSEMBLY INSTRUCTIONS**

## STEP 3



## STEP 4




PAGE 5 OF 6

COASTERFURNITURE.COM


# COASTER


#### **ASSEMBLY INSTRUCTIONS**

## STEP 5




# STEP 6 COMPLETE









Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

121251 Dining Table

REVISION 0 : 11/14/2023

PAGE 1 OF 5

COASTERFURNITURE.COM



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

#### PARTS IDENTIFICATION

A TOP 1PC


B LEG 4PCS

#### HARDWARE IDENTIFICATION

1	BOLT (M8 X 95mm - BLK)	<b>⊕</b>	8PCS
2	ALLEN WRENCH (M5 x 60mm - BLK)		1PC
3	LOCK WASHER (M8 x 14mm - BLK)		8PCS
4	FLAT WASHER (M8 x 22mm - BLK)		8PCS




# ASSEMBLY INSTRUCTIONS STEP 1




# STEP 2 2.1 Unlock 2.2 Lock PAGE 3 OF 5 COASTERFURNITURE.COM



# ASSEMBLY INSTRUCTIONS STEP 3




# STEP 4






# ASSEMBLY INSTRUCTIONS STEP 5 COMPLETE









Note: Dimension tolerance ± 5%