

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

122160BLKB1
DINING TABLE BASE

REVISION 0 : 08/19/2026

ITEM:122160BLKB1

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 25 MINUTES


PARTS IDENTIFICATION

A GLASS
GLASS SOLD SEPARATELY




1PC

B TOP FRAME




1PC

C LEG



4PCS

D LARGE CROSSBAR



1PC


ITEM:122160BLKB1

ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION



E SMALL CROSSBAR



2PCS

Z

HARDWARE IDENTIFICATION

1 SHORT BOLT
(1/4" x 15mm)



18PCS

3 SUCTION CUP



4PCS

2 LEVELER
(1/4" x 12mm)



4PCS

4 COVER





8PCS

5 ALLEN WRENCH
(4mm)




1PC


STEP 1



ITEM:122160BLKB1
ASSEMBLY INSTRUCTIONS
STEP 2



STEP 3




ITEM: 122160BLKB1
ASSEMBLY INSTRUCTIONS



STEP 4

GLASS (PART# A) SOLD SEPARATELY



STEP 5
COMPLETE


GLASS (PART# A) SOLD SEPARATELY



ITEM:122160BLKB1 ASSEMBLY INSTRUCTIONS



GLASS (PART# A) SOLD SEPARATELY



Note : Dimension tolerance $\pm 5\%$