



# *ASSEMBLY INSTRUCTIONS*

## *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**122341**  
**Dining Table**

REVISION 0: 05/05/2023  
REVISION 1: 11/16/2023

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM:122341



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

## PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		4PCS
C	TOP TRESTLE BAR		2PCS
D	STRETCHER BAR		2PCS
E	STRETCHER		2PCS
F	CROSSBAR		1PC

## HARDWARE IDENTIFICATION


1	BIG BOLT (M8 x 50mm - RBW)		22PCS
2	SMALL BOLT (M6 x 40mm - RBW)		4PCS
3	BIG LOCK WASHER (M8 - RBW)		22PCS
4	SMALL LOCK WASHER (M6 - RBW)		4PCS
5	WOOD DOWEL (M10 x 35mm - NTL)		14PCS
6	BIG ALLEN WRENCH (M5 x 65mm - BLK)		1PC
7	SMALL ALLEN WRENCH (M4 x 110mm - BLK)		1PC

ITEM: **122341**




**ASSEMBLY INSTRUCTIONS**

**STEP 1**



**STEP 2**




ITEM:122341




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **122341**




## ASSEMBLY INSTRUCTIONS

### STEP 5

\* Do not fully tighten the bolts (hardware#1) until all the 8pcs bolts have been screwed into place.



### STEP 6 COMPLETE





ITEM: **122341**




## ASSEMBLY INSTRUCTIONS

### STEP 7


\* To avoid scratching the table top. To extend the extension tops "please first pull down on the bottom of the extension top so it shows a slight opening"




### STEP 8




Once opening is shown, please slide back and the extension top can be popped up




### STEP 9



To put away the extension tops "please first pull back on the extension top and push down and the extension top can be stored below the table"



ITEM:122341



Note: Dimension tolerance  $\pm 5\%$



# *ASSEMBLY INSTRUCTIONS*

## *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**122342**  
**Dining Side Chair**



ITEM:122342



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES


## PARTS IDENTIFICATION

A BACK FRAME




1PC

B SEAT CUSHION WITH FRAME



1PC

C FRONT LEG



2PCS


## HARDWARE IDENTIFICATION

1 LONG BOLT  
(M6 X 80MM RBW)




4PCS

2 MEDIUM BOLT  
(M6 X 60MM RBW)



4PCS

3 SHORT BOLT  
(M6 X 40MM RBW)



2PCS

4 LOCK WASHER  
(M6 X 13MM RBW)



10PCS

5 FLAT WASHER  
(M6 X 19MM RBW)



10PCS

6 ALLEN WRENCH  
(M4 X 110MM RBW)



1PC

### NOTE:


Quantities shown are for one chair.

ITEM:122342


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM:122342


ASSEMBLY INSTRUCTIONS




STEP 3



STEP 4  
COMPLETE



ITEM:122342



Note: Dimension tolerance  $\pm 5\%$