

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

122509 Counter Stool

## ITEM: 122509

### **ASSEMBLY INSTRUCTION**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware form box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING:**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

# **PARTS IDENTIFICATION**

A SEAT AND BACK

B LEG FRAME

2PCS

C STRETCHER

2PCS

## HARDWARE IDENTIFICATION

1	BOLT (Ø1/4" x 35mm - RBW)	(0))))))))))	6PCS
2	LOCK WASHER (Ø5/16" x 13mm - RBW)		6PCS
3	FLAT WASHER (Ø5/16" x 19mm - RBW)		6PCS
4	PAN HEAD SCREW (Ø4" x 35mm - RBW)	( <del>) - 11111111&gt;</del>	4PCS
5	ALLEN WRENCH (M4 x 59mm - RBW)		1PC

#### NOTE:


Phillips head screw driver is required in the assembly process. However, manufacturer does not provide this item.

# ITEM: 122509


# **ASSEMBLY INSTRUCTION**

# COASTER


## STEP 1




## STEP 2



STEP 3




STEP 4
COMPLETE



PAGE 3 OF 3

ITEM: 122509





**Note: Dimension tolerance ±5%**