

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

123052

SIDE CHAIR

REVISION 0: 04/07/2019 REVISION 1: 03/27/2020

REVISION 2: 07/28/2022 REVISION 3: 12/25/2024

REVISION 4: 02/06/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 123052

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

HARDWARE INDENTIFICATION

LARGE BOLT


Α		BACK FRAME	1PC
В		SEAT CUSHION	1PC
С	FE	FRONT LEG	2PCS

'		(M8×75mm)	4PCS
2	<u>(————</u>	SMALL BOLT (M8×65mm)	4PCS
3	<u>(</u>	SMALL BOLT (M8×55mm)	1PC
4		ALLEN KEY (M8)	1PC
5		LOCK WASHER (Ф8)	9PCS
6		FLAT WASHER (Φ8)	9PCS

ITEM: 123052

ASSEMBLY INSTRUCTIONS






ITEM: **123052**

COASTER FINE FURNITURE

ASSEMBLY INSTRUCTIONS





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

180200 (B1&B2)
<u>Dining Table</u>

REVISION 0: 06/21/2024 REVISION 1: 02/22/2025

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM: 180200(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

20 MINUTES

PART IDENTIFICATION

B1 (BOX 1)

AN TOP



1PC

B2 (BOX 2)

BN	PEDESTAL	COLUMN
----	-----------------	--------



1PC

CN UPPER MOUNTING BAR



1PC

DN LOWER MOUNTING BAR



1PC

EN UPPER BASE



1PC

FN LOWER BASE



1PC

ITEM: 180200(B1&B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 180200 (B1)

1	LONG BOLT (5/16" x 75mm - BLK)		4PCS
2	SHORT BOLT (5/16" x 55mm - BLK)		4PCS
3	LOCK WASHER (1.6 x 14mm - BLK)		12PCS
4	SMALL FLAT WASHER (1 x 18mm - BLK)		8PCS
5	BIG FLAT WASHER (2 x 25mm - BLK)		4PCS
6	THREADED BOLT (5/16" x 125mm - WHT)		4PCS
7	HEX NUT (5/16" x 12 - BLK)		4PCS
8	WRENCH (M12 - WHT)		1PC
9	FLAT HEAD SCREW (8 x 50mm - BLK)	**************************************	4PCS


NOTE:

Philips head screw driver is required in the assembly process; however, manufacturer does not


ITEM: 180200(B1&B2) ASSEMBLY INSTRUCTIONS



COASTERFURNITURE.COM



STEP 2




PAGE 4 OF 6


ITEM: 180200(B1&B2) ASSEMBLY INSTRUCTIONS

COASTER

STEP 3



STEP 4




PAGE 5 OF 6

COASTERFURNITURE.COM


ITEM: 180200(B1&B2) **ASSEMBLY INSTRUCTIONS**



STEP 5




STEP 6 **COMPLETE**



ITEM: 180200(B1&B2)





Note: Dimension tolerance ±5%