

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

182475CRM
Swivel Bar Chair

ITEM: **182475CRM**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT CUSHION



1PC

B LOWER LEG FRAME



1PC

C UPPER LEG FRAME



1PC

D LEG



4PCS

E SWIVEL PLATE



1SET

F FOOTREST FRAME



1PC

G LEFT BACK SUPPORT



1PC

H RIGHT BACK SUPPORT



1PC

I BACK CUSHION



1PC

HARDWARE IDENTIFICATION

1 SHORT BOLT
(M6 x 20MM - BLK)



16PCS

2 LONG BOLT
(M6 x 30MM - BLK)



9PCS

3 LOCK WASHER
(1/4" x 12 Ø - BLK)



25PCS

4 FLAT WASHER
(1/4" x 19 Ø - BLK)



13PCS

5 ALLEN WRENCH
(M4 x 65MM - BLK)



1PC

NOTE:


Quantities Shown are for one Chair.

ITEM: **182475CRM**

ASSEMBLY INSTRUCTIONS


STEP 1

DO NOT TIGHTEN BOLT.




STEP 2

DO NOT TIGHTEN BOLT.



STEP 3

DO NOT TIGHTEN BOLT.




ITEM: **182475CRM**

ASSEMBLY INSTRUCTIONS


STEP 4

ADJUST THE LEG CONNECTIONS TO LEVEL BEFORE TIGHTENING ALL BOLTS.



STEP 5


TIGHTEN THE BOLTS IN THIS STEP.




ITEM: **182475CRM**

ASSEMBLY INSTRUCTIONS

STEP 6




STEP 7



ITEM: **182475CRM**

ASSEMBLY INSTRUCTIONS


STEP 8



STEP 9
COMPLETE



ITEM: **182475CRM**



Note: Dimension tolerance $\pm 5\%$