



ASSEMBLY INSTRUCTIONS *COASTER FINE FURNITURE*



Fine Furniture for every stage of life

182718GRY
Adjustable Bar Chair

ITEM: **182718GRY**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A SEAT AND BACK




1PC

B FOOTREST



1PC

C GAS LIFT



1PC

D BASE



1PC

HARDWARE IDENTIFICATION

1 BOLT
(Ø1/4 x 15mm - SR)



4PCS

2 LOCK WASHER
(Ø1/4" x 12mm - SR)



4PCS

3 FLAT WASHER
(Ø1/4" x 16mm - SR)



4PCS

4 ALLEN WRENCH
(M5 x 59mm - SR)



1PC


NOTE:

Phillips head screwdriver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **182718GRY**
ASSEMBLY INSTRUCTIONS




STEP 1




STEP 2




STEP 3



STEP 4
COMPLETE



ITEM: **182718GRY**



Note: Dimension tolerance $\pm 5\%$