



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

190242
Side Chair

ITEM:190242

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT AND BACK



1PC

B LEFT LEG FRAME



1PC

C RIGHT LEG FRAME



1PC

HARDWARE IDENTIFICATION

1 BOLT
(5/16" x 38mm - BLK)



4PCS

2 LOCK WASHER
(5/16" x 14mm - BLK)



4PCS

3 FLAT WASHER
(Ø1/4" x 16mm - SR)



4PCS

4 ALLEN WRENCH
(4mm x 64mm - BLK)



1PC

5 WOOD DOWEL
(10mm x 30mm)



2PCS

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **190242**

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3 COMPLETE



ITEM: **190242**



Note: Dimension tolerance $\pm 5\%$