

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

190821 Dining Table

REVISION 0: 05/30/2018 REVISION 1: 12/23/2020

PAGE 1 OF 3

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A TOP



1PC

B LEG



4PCS


HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 63mm - BLK)	1PC
2	BOLT (M6 x 60mm - RBW)	8PCS
3	LOCK WASHER (1/4" - BLK)	8PCS
4	FLAT WASHER (5/16" - RBW)	8PCS

ASSEMBLY INSTRUCTIONS

COASTER


STEP 1




STEP 2 COMPLETE




PUSH IN THE WOOD RUNNER TO FOLD DOWN THE LEAF.



PULL OUT THE WOOD RUNNER TO HOLD THE LEAF IN PLACE.






COASTERFURNITURE.COM

PAGE 3 OF 3





Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

190822 *Dining Side Chair*

REVISION 0: 05/30/2018 REVISION 1: 12/23/2020

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

Α	BACK FRAME	1PC
В	FRONT LEG FRAME	1PC
С	SIDE RAIL	2PCS
D	SEAT CUSHION	1PC

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110MM - BLK)	1PC
2	BOLT (M6 x 50MM - RBW)	6PCS
3	LOCK WASHER (1/4" - BLK)	6PCS
4	FLAT WASHER (M6 x 13MM - RBW)	6PCS
5	PAN HEAD SCREW (#8 x 1" - BLK)	 4PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer not provide this item. Quantities shown are for one chair.


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS


STEP 3






STEP 4 COMPLETE





COASTERFURNITURE.COM





Note: Dimension tolerance ±5%