



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

192522
Side Chair

ITEM: **192522**

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	BACKREST		1PC
B	SEAT CUSHION		1PC
C	LOWER LEG FRAME		1PC
D	UPPER LEG FRAME		1PC
E	FRONT CORNER BLOCK (LONG)		1PC
F	SIDE CORNER BLOCK (MEDIUM)		2PCS
G	BACK CORNER BLOCK (SHORT)		1PC

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 X 60MM - RBW)		1PC
2	BOLT (M6 X 45MM - RBW)		4PCS
3	HEX HEAD SCREW (M6 X 50MM - RBW)		1PC
4	LOCK WASHER (M6 X 13MM - RBW)		4PCS
5	FLAT WASHER (M6 X 13MM - RBW)		4PCS
6	LONG FLAT HEAD SCREW (M4 X 45MM - RBW)		4PCS
7	SHORT FLAT HEAD SCREW (M4 X 30MM - RBW)		16PCS
8	WOOD BUTTON		4PCS
9	FELT PAD (3 X 21MM)		4PCS


NOTE :

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **192522**


ASSEMBLY INSTRUCTIONS

STEP 1




*BOTTOM VIEW

STEP 2




STEP 3




ITEM: **192522**

ASSEMBLY INSTRUCTIONS


STEP 4




STEP 5



STEP 6 **COMPLETE**



ITEM: **192522**



Note: Dimension tolerance $\pm 5\%$