


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

DINING TABLE BASE

REVISION 0: 12/29/2020 REVISION 1: 07/26/2023

PAGE 1 OF 7



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 30 MINUTES


PARTS IDENTIFICATION

GLASS 1PC *GLASS SOLD SEPARATELY.* В **TOP FRAME** 1PC BASE FRAME C 4PCS HARDWARE IDENTIFICATION **BOLT** 1 12PCS (1/4" x 12mm SR) 2 SUCTION CUP 4PCS **LEVELER** 3 4PCS (1/4" x 12mm SR) ALLEN KEY 4 1PC (4mm) PAGE 2 OF 7 COASTERFURNITURE.COM




STEP 1

Do not tighten until each step is completed or instructed.



STEP 2




PAGE 3 OF 7


ITEM:193430 ASSEMBLY INSTRUCTIONS STEP 3 1 PAGE 4 OF 7 COASTERFURNITURE.COM



STEP 4




STEP 5



PAGE 5 OF 7




STEP 6 *GLASS SOLD SEPARATELY.*



$\underline{STEP~7}~* \texttt{GLASS}~ \texttt{SOLD}~ \texttt{SEPARATELY.*}$

COMPLETE




PAGE 6 OF 7



Product Size: 889 DIA X 743 H (MM)


Product Size: 35" DIA X 29.25"



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

DINING TABLE BASE

REVISION 0: 12/29/2020 REVISION 1: 07/26/2023

PAGE 1 OF 7



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 30 MINUTES


PARTS IDENTIFICATION

GLASS 1PC *GLASS SOLD SEPARATELY.* В **TOP FRAME** 1PC BASE FRAME C 4PCS HARDWARE IDENTIFICATION **BOLT** 1 12PCS (1/4" x 12mm SR) 2 SUCTION CUP 4PCS **LEVELER** 3 4PCS (1/4" x 12mm SR) ALLEN KEY 4 1PC (4mm) PAGE 2 OF 7 COASTERFURNITURE.COM




STEP 1

Do not tighten until each step is completed or instructed.



STEP 2




PAGE 3 OF 7


ITEM:193430 ASSEMBLY INSTRUCTIONS STEP 3 1 PAGE 4 OF 7 COASTERFURNITURE.COM



STEP 4




STEP 5



PAGE 5 OF 7




STEP 6 *GLASS SOLD SEPARATELY.*



$\underline{STEP~7}~* \texttt{GLASS}~ \texttt{SOLD}~ \texttt{SEPARATELY.*}$

COMPLETE




PAGE 6 OF 7



Product Size: 889 DIA X 743 H (MM)

Product Size: 35" DIA X 29.25"



Note: Dimension tolerance ±5%

