

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

193651(B1&B2)
Dining Table

ITEM: 193651(B1&B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.






ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	TOP		1PC
B	APRON		2PCS
C	CROSSBAR		1PC

B2 (BOX 2)

D	LEG FRAME		2PCS
---	-----------	---	------

ITEM: 193651(B1&B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.











WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 193651(B2)

1	ALLEN WRENCH (M4 x 100mm - BLK)		1PC
2	BOLT (M6 x 40mm - RBW)		14PCS
3	LOCK WASHER (M6 - RBW)		14PCS
4	FLAT WASHER (M6 - RBW)		12PCS
5	PLASTIC DOWEL (M8 x 30mm - BLK)		8PCS
6	FLAT HEAD SCREW (M4 x 38mm - RBW)		12PCS
7	WOOD PLUG		2PCS
8	LEVELER (M6 x 23mm - BLK)		4PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **193651(B1&B2)**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **193651(B1&B2)**




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **193651(B1&B2)**




ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6




ITEM: **193651(B1&B2)**




ASSEMBLY INSTRUCTIONS


STEP 7



STEP 8 COMPLETE



ITEM: 193651(B1&B2)



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

193652
Dining Chair

ITEM: **193652**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A BACK FRAME



1PC

B SEAT FRAME




1PC

C SEAT CUSHION



1PC

D FRONT LEG



2PCS

NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **193652**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:








1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100mm - BLK)		1PC
2	SHORT BOLT (M6 x 40mm - RBW)		2PCS
3	MEDIUM BOLT (M6 x 60mm - RBW)		4PCS
4	LONG BOLT (M6 x 70mm - RBW)		4PCS
5	LOCK WASHER (M6 - RBW)		10PCS
6	FLAT WASHER (M6 - RBW)		10PCS
7	FLAT HEAD SCREW (M4 x 25mm - RBW)		5PCS

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **193652**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **193652**




ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4 COMPLETE



ITEM: 193652



Note: Dimension tolerance $\pm 5\%$