

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 04/13/2016 REVISION 1 : 08/15/2019

PAGE 1 OF 4

# ITEM:200891KE (B1&B2)

### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



# ITEM:200891KE (B1&B2)

### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

### **HARDWARE IDENTIFICATION**


### Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 200891KE (B1)


1	BOLT (M6 x 30mm - BLK)		6PCS
2	LOCK WASHER (1/4" - BLK)	Ø	6PCS
3	FLAT WASHER (1/4"ID x 13mm - BLK)	$\bigcirc$	6PCS
4	ALLEN WRENCH (M4 x 60mm - BLK)		1PC
5	FLAT HEAD SCREW (M4 x 32mm - RBW)		8PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.










# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 04/13/2016 REVISION 1 : 08/15/2019



### ITEM: 200892 ASSEMBLY INSTRUCTIONS



#### ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



### ASSEMBLY TIME

5 MINUTES

### PARTS IDENTIFICATION

A NIGHTSTAND



1PC

#### B BUN FOOT


4PCS

PAGE 2 OF 3


# ITEM:200892 ASSEMBLY INSTRUCTIONS



### <u>STEP 1</u>



STEP 2




### STEP 3 COMPLETE



PAGE 3 OF 3







# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 04/13/2016 REVISION 1 : 06/15/2017 REVISION 2 : 08/15/2019

PAGE 1 OF 3

### ITEM: 200893 ASSEMBLY INSTRUCTIONS



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



### ASSEMBLY TIME



### **PARTS IDENTIFICATION**

A DRESSER



1PC

B BUN FOOT




4PCS

# ITEM:200893 ASSEMBLY INSTRUCTIONS




### <u>STEP 1</u>



#### **BOTTOM DRAWER BOX**

STEP 2



### STEP 3 COMPLETE



PAGE 3 OF 3



