

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

# 202411F (B1&B2) Full Bed

REVISION 0: 04/24/2012 REVISION 1: 11/29/2017 REVISION 2: 09/20/2018 REVISION 3: 11/29/2019 REVISION 4: 08/01/2024

PAGE 1 OF 6

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

## **PARTS IDENTIFICATION**

#### **B1 (BOX 1)**

<u>B1</u>	<u>( BOX 1)</u>			-				
AN	HEADBOARD PANEL		1PC	HBN	202411F(B1) *FROM BOX 1 HEADBOARD COMPLETE		1PC	
BN	LEFT HEADBOARD LEG		1PC	FBN	202411F(B1) *FROM BOX 1 FOOTBOARD		1PC	
CN	RIGHT HEADBOARD LEG		1PC			<b>(</b> )		
DN	FOOTBOARD PANEL		1PC					
EN	LEFT FOOTBOARD LEG		1PC					
FN	RIGHT FOOTBOARD LEG		1PC					
B2 ( BOX 2)								

GN	BED RAIL		2PCS
HN	BED SLAT		4PCS
IN	BED SLAT SUPPORT WITH LEVELER	€	4PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

1. Remove hardware from box and sort by size.

DOL T

- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

0

#### **HARDWARE IDENTIFICATION**

#### Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 202411F(B1)


1	BOLT (M6 x 35mm - BLK)	12PCS
2	LOCK WASHER (M6 - BLK)	12PCS
3	SMALL FLAT WASHER (M6 x 13mm - BLK)	4PCS
4	BIG FLAT WASHER (M6 x 19mm - BLK)	8PCS
5	ALLEN WRENCH (M4 x 65mm - BLK)	1PC
6	WOOD PLUG (14.50mm - CHY)	4PCS
7	PAN HEAD SCREW (M4 x 30mm - BLK)	8PCS

#### NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

# **ASSEMBLY INSTRUCTIONS** 202411F (B1) - BOX 1

#### STEP 1




## STEP 2






# ASSEMBLY INSTRUCTIONS 202411F (B1&B2) - BOX 1 & BOX 2 STEP 3



## STEP 4




PAGE 5 OF 6



ASSEMBLY INSTRUCTIONS

STEP 5


COMPLETE







Inner Size: 54.75"W x 75.50"D



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

202413 *Dresser* 

REVISION 0 : 10/22/2012 REVISION 1 : 09/20/2018 REVISION 2 : 11/29/2019 REVISION 3 : 07/30/2024

PAGE 1 OF 2

ITEM: 202413



# ANTI-TIPPING INSTALLATION INSTRUCTIONS FURNITURE TIPPING RESTRAINT

#### WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer : 23.00"W X 12.25"D X 4.00"H X 0.50"T



**Note: Dimension tolerance ±5%** 



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

202414 *Mirror* 

REVISION 0 : 04/24/2012 REVISION 1 : 09/20/2018 REVISION 2 : 11/29/2019

PAGE 1 OF 4

## ITEM: 202414

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

#### **PARTS IDENTIFICATION**

AN MIRROR



1PC

DRESSER FROM BOX ITEM# 202413



1PC

CN MIRROR SUPPORT FROM BOX ITEM# 202413



2PCS

#### **HARDWARE IDENTIFICATION**

PAN HEAD SCREW (M4 x 32mm - BLK)



6PCS

#### NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

# ITEM:202414




# ASSEMBLY INSTRUCTIONS


## STEP 1



## STEP 2




# STEP 3 COMPLETE



PAGE 3 OF 3







Note: Dimension tolerance ±5%