




ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204190KE(B1-B4) *Eastern King Storage Bed*

REVISION 0 : 04/08/2016
REVISION 1 : 11/14/2016
REVISION 2 : 11/12/2019

ITEM: 204190KE(B1-B4)

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


B1 (BOX 1)

A HEADBOARD PANEL




1PC

B LEFT HEADBOARD LEG




1PC

C RIGHT HEADBOARD LEG



1PC


D FOOTBOARD



1PC


B2 (BOX 2)

E LEFT BED RAIL




1PC

F RIGHT BED RAIL



1PC

G BED SLAT WITH 3 HOLES




3PCS

H DRAWER SLAT




2PCS

I ROLL SLAT (5PCS)




2SETS

J STORAGE FOOTBOARD SUPPORT LEG




2PCS

K CENTER RAIL SUPPORT WITH LEVELER




3PCS

L CENTER RAIL



1PC


M BOTTOM CROSS BAR



3PCS

B3 (BOX 3)


N DRAWER BOX



2PCS


B4 (BOX 4)

O DRAWER BOX




2PCS

HB 204190KE (B1)
FROM BOX 1
HEADBOARD COMPLETE



1PC

D 204190KE (B1)
FROM BOX 1
FOOTBOARD



1PC

ITEM: 204190KE(B1-B4)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 204190KE (B1)

1 BOLT
(M6 x30mm - BLK)



6PCS

3 FLAT WASHER
(1/4" x13mm - BLK)



6PCS

2 LOCK WASHER
(1/4" - BLK)



6PCS


4 ALLEN WRENCH
(M4 x 65mm - BLK)



1PC

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 204190KE (B2)

5 BOLT
(M6 x50mm - BLK)



5PCS

8 SMALL ALLEN
WRENCH
(M4 x 65mm - BLK)



1PC

6 LONG FLAT HEAD
SCREW
(M4 x 32mm - RBW)



43PCS

9 BIG ALLEN
WRENCH
(M5 x 65mm - BLK)



1PC

7 SHORT FLAT HEAD
SCREW
(M4 x 16mm - RBW)




4PCS

NOTE:


Philips head screw driver in the assembly process ; however, manufacturer does not provide the item

ITEM: **204190KE(B1-B4)**
ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: 204190KE(B1-B4)

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4





ITEM: **204190KE(B1-B4)**
ASSEMBLY INSTRUCTIONS



STEP 5



STEP 6
COMPLETE




ITEM: **204190KE(B1-B4)**



Inner Size : 73.25"W X 81.75"D

Inner Size of Drawer : 24.00"W X 17.75"D X 5.75"H X 0.25T



Note : Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204192
Nighstand

REVISION 0 : 06/17/2015
REVISION 1 : 12/17/2017
REVISION 2 : 06/04/2019

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: **204192**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING !



- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B RIGHT FRONT LEG
(WITH FR LABEL)



1PC

C LEFT FRONT LEG
(WITH FR LABEL)



1PC

D RIGHT BACK LEG
(WITH BR LABEL)



1PC


E LEFT BACK LEG
(WITH BR LABEL)



1PC

HARDWARE IDENTIFICATION

1 BOLT
(M6 x 35mm - BLK)



8PCS

3 FLAT WASHER
(1/4" x 20mm - BLK)



8PCS

2 LOCK WASHER
(1/4" - BLK)



8PCS

4 ALLEN WRENCH
(M4 x 65mm - BLK)



1PC


NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


ITEM: **204192**
ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2



ITEM: **204192**
ASSEMBLY INSTRUCTIONS




STEP 3
COMPLETE



ITEM: **204192**



Inner Size Of Drawer : 12.75"W X 12.75"D X 5.00"H X 0.25"T



Note : Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204193
Dresser

REVISION 0 : 06/17/2015
REVISION 1 : 12/17/2017
REVISION 2 : 06/04/2019
REVISION 3 : 10/09/2024

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: **204193**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING !









- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.







ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

| | | | | | | | |
|---|------------------------------------|---|-----|---|------------------------------------|---|-----|
| A | DRESSER |  | 1PC | D | RIGHT BACK LEG (WITH BR LABEL) |  | 1PC |
| B | RIGHT FRONT LEG (WITH FR LABEL) |  | 1PC | E | LEFT BACK LEG (WITH BL LABEL) |  | 1PC |
| C | LEFT FRONT LEG (WITH FL LABEL) |  | 1PC | F | CENTER SUPPORT LEG WITH LEVELER |  | 1PC |

HARDWARE IDENTIFICATION

| | | | | | | | |
|---|-----------------------------|---|------|---|------------------------------------|---|------|
| 1 | BOLT (M6 x 35mm - BLK) |  | 8PCS | 3 | FLAT WASHER (1/4" x 20mm - BLK) |  | 8PCS |
| 2 | LOCK WASHER (1/4" - BLK) |  | 8PCS | 4 | ALLEN WRENCH (M4 x 65mm - BLK) |  | 1PC |

NOTE:


Philips head screw driver in the assembly process ; however, manufacturer does not provide the item

ITEM: 204193


ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2



ITEM: **204193**
ASSEMBLY INSTRUCTIONS



STEP 3
COMPLETE




ANTI-TIPPING INSTALLATION INSTRUCTIONS
FURNITURE TIPPING RESTRAINT**WARNING**

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.


This restraint must be screwed to a wood stud on the wall, using the long screw provided.

STEP 1



Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.

**STEP 2**

Locate the wood stud on the wall and secure the other bracket 2 inches below the back of the unit, using the long screw.

**STEP 3**


Place the furniture into position so both mounting brackets are vertically in line. Lace the threaded end of the restraint strap through the hole in each mounting bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight. Ensure that the restraint strap is securely laced and locked.



ITEM: **204193**



Inner Size Of Drawer : 23.25"W X 12.75"D X 5.00"H X 0.25"T



Note : Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204194
Mirror

REVISION 0 : 06/17/2015
REVISION 1 : 12/17/2017
REVISION 2 : 06/04/2019

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: **204194**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING !



- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

20 MINUTES


PARTS IDENTIFICATION

A MIRROR




1PC

B MIRROR SUPPORT
(PACKED WITH DRESSER)



2PCS

C DRESSER
FROM BOX ITEM#204193



1PC

HARDWARE IDENTIFICATION

1 PAN HEAD SCREW
(M4 X32mm - BLK)



8PCS


NOTE:

Philips head screw driver in the assembly process ; however, manufacturer does not provide the item


ITEM: **204194**
ASSEMBLY INSTRUCTIONS



STEP 1





STEP 2




ITEM: **204194**
ASSEMBLY INSTRUCTIONS



STEP 3
COMPLETE



ITEM: **204194**



Note : Dimension tolerance $\pm 5\%$