

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 204190KW(B1-B4) California King Storage Bed

REVISION 0 : 04/08/2016 REVISION 1 : 11/14/2016 REVISION 2 : 11/12/2019

### ITEM: 204190KW(B1-B4)

## COASTER

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

# $\Lambda$

#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

### **PARTS IDENTIFICATION**

### **B1 (BOX 1)**

Α	HEADBOARD PANEL	1PC	K CENTER RAIL SUPPORT 3PCS WITH LEVELER
В	LEFT HEADBOARD LEG	1PC	L CENTER RAIL 1PC
С	RIGHT HEADBOARD LEG	1PC	M BOTTOM CROSS BAR 3PCS
D	FOOTBOARD	1PC	N RAIL TOP 2PCS
B	2 (BOX 2)		B3 (BOX 3)
E	LEFT BED RAIL	∰ 1PC	O DRAWER BOX 2PCS
F	RIGHT BED RAIL	1PC	B4 (BOX 4)
G	BED SLAT WITH 3 HOLES	3PCS	P DRAWER BOX 2PCS
н	DRAWER SLAT	2PCS	
I	ROLL SLAT (5PCS)	2SETS	HB 204190KW (B1) 1PC FROM BOX 1 HEADBOARD COMPLETE
J	STORAGE FOOTBOARD SUPPORT LEG	3PCS	D 204190KW (B1) 1PC FROM BOX 1 FOOTBOARD

### ITEM: 204190KW(B1-B4)

## COASTER

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

# $\Lambda$

#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

### **HARDWARE IDENTIFICATION**

#### Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 204190KW (B1)

1 BOLT (M6 x30mm - BLK)

6PCS

3 FLAT WASHER (1/4" x13mm - BLK)



6PCS

2 LOCK WASHER (1/4" - BLK)



6PCS

4 ALLEN WRENCH (M4 x 65mm - BLK)



1PC

### Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 204190KW (B2)

5 LONG BOLT (M6 x50mm - BLK)



5PCS

9 LONG FLAT HEAD SCREW (M4 x 32mm - RBW)



43PCS

6 SHORT BOLT (M6 x35mm - BLK)



8PCS

10 SHORT FLAT HEAD SCREW (M4 x 16mm - RBW)

4PCS

7 LOCK WASHER (1/4" - BLK)



8PCS

11 SMALL ALLEN WRENCH (M4 x 100mm - BLK)

8 FLAT WASHER (1/4" x20mm - BLK)



8PCS

12 BIG ALLEN WRENCH (M5 x 65mm - BLK)

1PC

1PC


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


# ITEM: 204190KW(B1-B4) ASSEMBLY INSTRUCTIONS



### STEP 1



### STEP 2




PAGE 4 OF 6

## ITEM: 204190KW(B1-B4)






### STEP 3




### STEP 4



# ITEM: 204190KW(B1-B4) ASSEMBLY INSTRUCTIONS



### STEP 5



# STEP 6 COMPLETE




PAGE 6 OF 6

## ITEM: 204190KW(B1-B4)



Inner Size: 73.50"W X 86.50"D

Inner Size of Drawer: 24.00"W X 17.75"D X 5.75"H X 0.25T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204192 Nighstand

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019

PAGE 1 OF 4

### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

### PARTS IDENTIFICATION

A NIGHTSTAND

1PC

D RIGHT BACK LEG (WITH BR LABEL)

1PC

E LEFT BACK LEG (WITH BR LABEL)

1PC

C LEFT FRONT LEG (WITH FR LABEL)

1PC

### HARDWARE IDENTIFICATION

1 BOLT (M6 x 35mm - BLK) 8PCS 3 FLAT WASHER (1/4" x 20mm - BLK) 8PCS (1/4" x 20mm - BLK) 1PC (1/4" - BLK) 1PC


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


### **ASSEMBLY INSTRUCTIONS**

### STEP 1






### STEP 2



# ITEM: **204192 ASSEMBLY INSTRUCTIONS**




STEP 3
COMPLETE







Inner Size Of Drawer: 12.75"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204193 *Dresser* 

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019 REVISION 3 : 10/09/2024

PAGE 1 OF 5

### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

# $\Lambda$

#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

### **PARTS IDENTIFICATION**

A	DRESSER	1PC	D RIGHT BACK LEG (WITH BR LABEL)	1PC
В	RIGHT FRONT LEG (WITH FR LABEL)	1PC	E LEFT BACK LEG (WITH BL LABEL)	1PC
С	LEFT FRONT LEG (WITH FL LABEL)	1PC	F CENTER SUPPORT LEG WITH LEVELER	1PC

### HARDWARE IDENTIFICATION


1	BOLT (M6 x 35mm - BLK)		8PCS	3	FLAT WASHER (1/4" x 20mm - BLK)	0	8PCS
2	LOCK WASHER (1/4" - BLK)	<b>(6)</b>	8PCS	4	ALLEN WRENCH (M4 x 65mm - BLK)		1PC

#### NOTE:


Philips head screw driver in the assembly process; however, manufacturer does not provide the item

### ITEM: **204193 ASSEMBLY INSTRUCTIONS**

### STEP 1



### STEP 2



### **ASSEMBLY INSTRUCTIONS**



STEP 3
COMPLETE







## ANTI-TIPPING INSTALLATION INSTRUCTIONS FURNITURE TIPPING RESTRAINT

#### **WARNING**

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitle for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


#### STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.




#### STEP 2

Locate the wood stud on the wall and secure the other bracket 2 inches below the back of the unit, using the long screw.




#### STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the threaded end of the restraint strap through the hole in each mounting bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight. Ensure that the restraint strap is securely laced and locked.








PAGE 5 OF 5



Inner Size Of Drawer: 23.25"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204194 *Mirror* 

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019

PAGE 1 OF 4

### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

### **PARTS IDENTIFICATION**

A MIRROR 1PC

B MIRROR SUPPORT (PACKED WITH DRESSER)

C DRESSER FROM BOX ITEM#204193

1PC

### **HARDWARE IDENTIFICATION**

1 PAN HEAD SCREW (M4 X32mm - BLK)



8PCS


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


### **ASSEMBLY INSTRUCTIONS**

# COASTER

### STEP 1




### STEP 2



# ITEM: **204194 ASSEMBLY INSTRUCTIONS**


# COASTER

STEP 3
COMPLETE









Note: Dimension tolerance ±5%



### ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204195 *Chest* 

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019 REVISION 3 : 10/09/2024

PAGE 1 OF 5

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

### **PARTS IDENTIFICATION**

A	CHEST	1PC	D RIGHT BACK LEG (WITH BR LABEL)	1PC
В	RIGHT FRONT LEG (WITH FR LABEL)	1PC	E LEFT BACK LEG (WITH BL LABEL)	1PC
С	LEFT FRONT LEG (WITH FL LABEL)	1PC		

### HARDWARE IDENTIFICATION


1	BOLT (M6 x 35mm - BLK)		8PCS	3	FLAT WASHER (1/4" x 20mm - BLK)	0	8PCS
2	LOCK WASHER (1/4" - BLK)	<b>(6)</b>	8PCS	4	ALLEN WRENCH (M4 x 65mm - BLK)		1PC

#### NOTE:


Philips head screw driver in the assembly process; however, manufacturer does not provide the item

### **ASSEMBLY INSTRUCTIONS**

### STEP 1



### STEP 2



# ITEM: **204195 ASSEMBLY INSTRUCTIONS**



# STEP 3 COMPLETE







## ANTI-TIPPING INSTALLATION INSTRUCTIONS FURNITURE TIPPING RESTRAINT

#### **WARNING**

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitle for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


#### STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.




#### STEP 2

Locate the wood stud on the wall and secure the other bracket 2 inches below the back of the unit, using the long screw.




#### STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the threaded end of the restraint strap through the hole in each mounting bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight. Ensure that the restraint strap is securely laced and locked.








PAGE 5 OF 5



Inner Size Of Drawer: 23.25"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%