

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204191KE (B1&B2) Eastern King Bed

REVISION 0 : 02/26/2017 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Λ

WARNING!

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


B1 (BOX 1)

A	HEADBOARD PANEL	1PC	D FOOTBOARD	1PC
В	RIGHT HEADBOARD LEG	1PC	E BED SLAT	4PCS
С	LEFT HEADBOARD LEG	1PC	F BED SLAT SUPPORT WITH LEVELER	8PCS

B2 (BOX 2)

G BED RAIL 2PCS

HB 204191KE (B1) (FROM BOX 1) HEADBOARD COMPLETE





1PC

COASTER

ASSEMBLY INSTRUCTIONS

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

\triangle

WARNING!

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

HARDWARE IDENTIFICATION

Z-B1 (BOX1) - HARDWARE PACK IS LOCATED IN 204191KE (B1)

1	BOLT (M6 x30mm - BLK)		6PCS	4	FLAT HEAD SCREW (M4 x 32mm - RBW)	Ammun	8PCS
2	LOCK WASHER (1/4" - BLK)	©	6PCS	5	SMALL ALLEN WRENCH (M4 x 65mm - BLK)		1PC
3	FLAT WASHER (1/4" x13mm - BLK)	0	6PCS	6	BIG ALLEN WRENCH (M5 x 65mm - BLK)		1PC


NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




PAGE 4 OF 5

ITEM: 204191KE(B1&B2) ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4 COMPLETE










Inner Size: 76.75"W X 81.00"D



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204192 Nighstand

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019

PAGE 1 OF 4

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND

1PC

D RIGHT BACK LEG (WITH BR LABEL)

1PC

E LEFT BACK LEG (WITH BR LABEL)

1PC

C LEFT FRONT LEG (WITH FR LABEL)

1PC

HARDWARE IDENTIFICATION

1 BOLT (M6 x 35mm - BLK) 8PCS 3 FLAT WASHER (1/4" x 20mm - BLK) 8PCS (1/4" x 20mm - BLK) 1PC (1/4" - BLK) 1PC


NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


ASSEMBLY INSTRUCTIONS

STEP 1






STEP 2



ITEM: **204192 ASSEMBLY INSTRUCTIONS**




STEP 3
COMPLETE







Inner Size Of Drawer: 12.75"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204193 *Dresser*

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019 REVISION 3 : 10/09/2024

PAGE 1 OF 5

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Λ

WARNING!

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A	DRESSER	1PC	D RIGHT BACK LEG (WITH BR LABEL)	1PC
В	RIGHT FRONT LEG (WITH FR LABEL)	1PC	E LEFT BACK LEG (WITH BL LABEL)	1PC
С	LEFT FRONT LEG (WITH FL LABEL)	1PC	F CENTER SUPPORT LEG WITH LEVELER	1PC

HARDWARE IDENTIFICATION


1	BOLT (M6 x 35mm - BLK)		8PCS	3	FLAT WASHER (1/4" x 20mm - BLK)	0	8PCS
2	LOCK WASHER (1/4" - BLK)	(6)	8PCS	4	ALLEN WRENCH (M4 x 65mm - BLK)		1PC

NOTE:


Philips head screw driver in the assembly process; however, manufacturer does not provide the item

ITEM: **204193 ASSEMBLY INSTRUCTIONS**

STEP 1



STEP 2



ASSEMBLY INSTRUCTIONS



STEP 3
COMPLETE







ANTI-TIPPING INSTALLATION INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitle for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.




STEP 2

Locate the wood stud on the wall and secure the other bracket 2 inches below the back of the unit, using the long screw.




STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the threaded end of the restraint strap through the hole in each mounting bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight. Ensure that the restraint strap is securely laced and locked.








PAGE 5 OF 5



Inner Size Of Drawer: 23.25"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204194 *Mirror*

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019

PAGE 1 OF 4

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A MIRROR 1PC

B MIRROR SUPPORT (PACKED WITH DRESSER)

C DRESSER FROM BOX ITEM#204193

1PC

HARDWARE IDENTIFICATION

1 PAN HEAD SCREW (M4 X32mm - BLK)



8PCS


NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1




STEP 2



ITEM: **204194 ASSEMBLY INSTRUCTIONS**


COASTER

STEP 3
COMPLETE









Note: Dimension tolerance ±5%