

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204191Q(B1&B2) Queen Bed

REVISION 0 : 02/26/2017 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019

## ITEM: 204191Q(B1&B2)

## COASTER

### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

### PARTS IDENTIFICATION

#### **B1 (BOX 1)**

A	HEADBOARD PANEL		1PC	D FOOTBOARD	1PC		
В	RIGHT HEADBOARD LEG		1PC	E BED SLAT	4PCS		
С	LEFT HEADBOARD LEG		1PC	F BED SLAT SUPPORT WITH LEVELER	4PCS		
B2 (BOX 2)							

G BED RAIL 2PCS

HB 204191Q (B1) (FROM BOX 1) HEADBOARD COMPLETE



ı

D 204191Q (B1) (FROM BOX 1) FOOTBOARD



1PC

## ITEM: 204191Q(B1&B2)

## COASTER

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

## M

#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

30 MINUTES

### **HARDWARE IDENTIFICATION**

#### Z-B1 (BOX1) - HARDWARE PACK IS LOCATED IN 204191Q (B1)

1	BOLT (M6 x30mm - BLK)		6PCS	4	FLAT HEAD SCREW (M4 x 32mm - RBW)	Finning	8PCS
2	LOCK WASHER (1/4" - BLK)	<b>©</b>	6PCS	5	SMALL ALLEN WRENCH (M4 x 65mm - BLK)		1PC
3	FLAT WASHER (1/4" x13mm - BLK)	0	6PCS	6	BIG ALLEN WRENCH (M5 x 65mm - BLK)		1PC


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


# ITEM: 204191Q(B1&B2) ASSEMBLY INSTRUCTIONS



## STEP 1



## STEP 2




PAGE 4 OF 5

# ITEM: 204191Q(B1&B2) ASSEMBLY INSTRUCTIONS



## STEP 3



## STEP 4 COMPLETE




PAGE 5 OF 5



## ITEM: **204191Q(B1&B2)**



Inner Size: 61.00"W X 81.00"D



**Note:** Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204192 Nighstand

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019 REVISION 3 : 11/17/2025

PAGE 1 OF 4

#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

## $\Lambda$

#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

### PARTS IDENTIFICATION

A NIGHTSTAND

1PC

D RIGHT BACK LEG (WITH BR LABEL)

1PC

E LEFT BACK LEG (WITH BL LABEL)

1PC

C LEFT FRONT LEG (WITH FL LABEL)

1PC

### HARDWARE IDENTIFICATION

1 BOLT (M6 x 35mm - BLK) 8PCS 3 FLAT WASHER (1/4" x 20mm - BLK) 8PCS
2 LOCK WASHER (1/4" - BLK) 8PCS 4 ALLEN WRENCH (M4 x 100mm - BLK) 1PC


#### NOTE:


Philips head screw driver in the assembly process; however, manufacturer does not provide the item

## **ASSEMBLY INSTRUCTIONS**











## STEP 3 COMPLETE




PAGE 3 OF 3





Inner Size Of Drawer: 12.75"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204193 *Dresser* 

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019 REVISION 3 : 10/09/2024 REVISION 4 : 11/17/2025

PAGE 1 OF 5

### **ASSEMBLY INSTRUCTIONS**

## COASTER

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

## M

#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

## **PARTS IDENTIFICATION**

A	DRESSER	1PC	D RIGHT BACK LEG (WITH BR LABEL)	1PC
В	RIGHT FRONT LEG (WITH FR LABEL)	1PC	E LEFT BACK LEG (WITH BL LABEL)	1PC
С	LEFT FRONT LEG (WITH FL LABEL)	1PC	F CENTER SUPPORT LEG WITH LEVELER	1PC

### HARDWARE IDENTIFICATION

1	BOLT (M6 x 35mm - BLK)		8PCS	3	FLAT WASHER (1/4" x 20mm - BLK)	0	8PCS
2	LOCK WASHER (1/4" - BLK)	<b>©</b>	8PCS	4	ALLEN WRENCH (M4 x 100mm - BLK)		1PC


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


# ITEM: **204193 ASSEMBLY INSTRUCTIONS**



## STEP 1



## STEP 2



### **ASSEMBLY INSTRUCTIONS**



## STEP 3 COMPLETE







## ANTI-TIPPING INSTALLATION INSTRUCTIONS FURNITURE TIPPING RESTRAINT

#### **WARNING**

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitle for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


#### STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.




#### STEP 2

Locate the wood stud on the wall and secure the other bracket 2 inches below the back of the unit, using the long screw.



#### STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the threaded end of the restraint strap through the hole in each mounting bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight. Ensure that the restraint strap is securely laced and locked.








PAGE 5 OF 5



Inner Size Of Drawer: 23.25"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204194 *Mirror* 

REVISION 0 : 06/17/2015 REVISION 1 : 12/17/2017 REVISION 2 : 06/04/2019

PAGE 1 OF 4

## COASTER

### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

### **PARTS IDENTIFICATION**

A MIRROR 1PC

B MIRROR SUPPORT (PACKED WITH DRESSER)

C DRESSER FROM BOX ITEM#204193

1PC

### **HARDWARE IDENTIFICATION**

1 PAN HEAD SCREW (M4 X32mm - BLK)



8PCS


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


## COASTER

## **ASSEMBLY INSTRUCTIONS**

## STEP 1



## STEP 2




PAGE 3 OF 4

# ITEM: **204194 ASSEMBLY INSTRUCTIONS**


## COASTER

STEP 3
COMPLETE









Note: Dimension tolerance ±5%