



Fine Furniture for every stage of life



PAGE 1 OF 6

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 205111F (B1)





2.1

R

P

R Æ

2.2

 \mathbf{E}

12


C

12

ĸ

ASSEMBLY INSTRUCTIONS








PAGE 4 OF 6



ASSEMBLY INSTRUCTIONS











Fine Furniture for every stage of life



REVISION 0 : 08/08/2016 REVISION 1 : 07/24/2017 REVISION 2 : 09/04/2018 REVISION 3 : 10/25/2019



ITEM:205112 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION


A NIGHTSTAND



1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.







Inner Size of Drawer A: 18.00"W X 12.50"D X 4.00"H X 0.25"T Inner Size of Drawer B: 18.00"W X 12.50"D X 1.25"H X 0.25"T



Note: Dimension tolerance ±5%





Fine Furniture for every stage of life

205113 <u>Dresser</u>

REVISION 0 : 08/08/2016 REVISION 1 : 07/24/2017 REVISION 2 : 09/04/2018 REVISION 3 : 10/25/2019



ITEM:205113 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

DRESSER





1PC

NOTE:

Α

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.









Fine Furniture for every stage of life



REVISION 0 : 08/08/2016 REVISION 1 : 09/04/2018 REVISION 2 : 12/07/2018 REVISION 3 : 10/25/2019 REVISION 4 : 08/25/2023



ITEM: 205114 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ITEM: 205114



ASSEMBLY INSTRUCTIONS

<u>STEP 1</u>


ARROW MARKING FACE UPWARD Ĉ (\mathbf{A}) STEP 2 **ARROW MARKING FACE UPWARD** (5 9 (\mathbf{C}) 4 00 (\mathbf{A}) **BACK VIEW** PAGE 3 OF 4 COASTERFURNITURE.COM


ITEM: 205114



ASSEMBLY INSTRUCTIONS

STEP 3









Fine Furniture for every stage of life



REVISION 0 : 08/08/2016 REVISION 1 : 07/24/2017 REVISION 2 : 09/04/2018 REVISION 3 : 10/25/2019



ITEM:205115 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

Α

CHEST



1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

