

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

205131T (B1-B3) Twin Bed

REVISION 0 : 12/06/2024



COASTERFURNITURE.COM

#### **ASSEMBLY INSTRUCTIONS**


#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

35 MINUTES

### PARTS IDENTIFICATION

#### **B1 (BOX 1)**

Α	HEADBOARD PANEL		1PC	
В	LEFT HEADBOARD LEG		1PC	
С	RIGHT HEADBOARD LEG		1PC	
B2 ( BOX 2 )				
D	FOOTBOARD PANEL		1PC	
E	FOOTBOARD LEG		2PCS	
B3 ( BOX 3 )				
F	BED RAIL		2PCS	
G	ROLL SLAT (7PCS)		2SETS	
НВ	205131T (B1) FROM BOX 1 HEADBOARD COMPLETE		1PC	
FB	205131T (B2) FROM BOX 2 FOOTBOARD COMPLETE		1PC	

PAGE 2 OF 6



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

### HARDWARE IDENTIFICATION

#### Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 205131T (B3)

1	ALLEN WRENCH (M4 x 110mm - BLK)		1PC
2	SHORT BOLT WITH WASHER (M6 x 25mm - BLK)	9000°	8PCS
3	LONG BOLT WITH WASHER (M6 x 45mm - BLK)	9-1919D	8PCS
4	FLAT HEAD SCREW (#8 x 1 1/8" - BLK)	& Thinks	28PCS


#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


# COASTER

## **ASSEMBLY INSTRUCTIONS**

## STEP 1



# STEP 2




PAGE 4 OF 6


# COASTER

## **ASSEMBLY INSTRUCTIONS**

# STEP 3



# STEP 4



PAGE 5 OF 6

## **ASSEMBLY INSTRUCTIONS**

# STEP 9 COMPLETE










Inner Size: 39.50"W x 76.00"D



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

# 205132 Nightstand

REVISION 0 : 08/17/2018 REVISION 1 : 12/04/2019 REVISION 2 : 08/04/2020 REVISION 3 : 07/05/2024

PAGE 1 OF 4



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

### PARTS IDENTIFICATION

AM NIGHTSTAND



1PC

BM LEG



4PCS

### HARDWARE IDENTIFICATION

1 ALLEN WRENCH (M4 - BLK)



1PC

2 BOLT WITH WASHER (M6 x 25mm - BLK)




12PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




# ASSEMBLY INSTRUCTIONS STEP 1



# STEP 2 COMPLETE







#### ANTI-TIPPING INSTALLMENT INSTRUCTIONS

### **FURNITURE TIPPING RESTRAINT**

#### **WARNING**

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer : 20.75"W x 12.25"D x 5.50"H x 0.50"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**205133 Dresser** 

REVISION 0 : 08/17/2018 REVISION 1 : 12/04/2019 REVISION 2 : 08/04/2020 REVISION 3 : 07/05/2024

PAGE 1 OF 4



### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

### **PARTS IDENTIFICATION**

AM DRESSER

1PC

BM LEG

4PCS

CM CENTER SUPPORT LEG WITH LEVELER

1PC

### HARDWARE IDENTIFICATION

1 ALLEN WRENCH (M4 - BLK)


2 BOLT WITH WASHER (M6 x 25mm - BLK) 12PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



# ASSEMBLY INSTRUCTIONS STEP 1



# STEP 2 COMPLETE







#### ANTI-TIPPING INSTALLMENT INSTRUCTIONS

### **FURNITURE TIPPING RESTRAINT**

#### **WARNING**

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer : 25.75"W x 13.75"D x 5.50"H x 0.50"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

205134 *Mirror* 

REVISION 0 : 08/17/2018 REVISION 1 : 12/04/2019 REVISION 2 : 08/04/2020 REVISION 3 : 09/04/2023

PAGE 1 OF 3



#### **ASSEMBLY INSTRUCTIONS**


#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



**ASSEMBLY TIME** 

10 MINUTES

### PARTS IDENTIFICATION

1PC AM **MIRROR DRESSER** BM 1PC \*FROM BOX ITEM #205133 MIRROR SUPPORT 

### HARDWARE IDENTIFICATION

1PC **ALLEN WRENCH** 1 (M4 - BLK) **BOLT WITH WASHER** 

(M6 x 35mm - BLK)

(PACKED WITH DRESSER)

#### NOTE:

2

CM

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


2PCS

8PCS

### **ASSEMBLY INSTRUCTIONS**

# COASTER'

## STEP 1




## STEP 2 COMPLETE









Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

205135 Chest

REVISION 0 : 08/17/2018 REVISION 1 : 12/04/2019 REVISION 2 : 08/04/2020 REVISION 3 : 07/05/2024

PAGE 1 OF 3



### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

### **PARTS IDENTIFICATION**

AM CHEST



1PC

BM LEG



4PCS

### HARDWARE IDENTIFICATION

1 ALLEN WRENCH (M4 - BLK)



1PC

2 BOLT WITH WASHER (M6 x 25mm - BLK)




12PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



# ASSEMBLY INSTRUCTIONS STEP 1



# STEP 2 COMPLETE



**V**△**y** 



#### ANTI-TIPPING INSTALLMENT INSTRUCTIONS

### **FURNITURE TIPPING RESTRAINT**

#### **WARNING**

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer : 29.75"W x 12.75"D x 5.50"H x 0.50"T



Note: Dimension tolerance ±5%