

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

212421KE (B1&B2) <u>Eastern King Bed</u>

REVISION 0 : 10/16/2017 REVISION 1 : 08/09/2018 REVISION 2 : 08/28/2018 REVISION 3 : 01/02/2019 REVISION 4 : 12/13/2019



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

	<u>. </u>						
A	HEADBOARD PANEL		1PC	D	LEFT HEADBOARD LEG		1PC
В	FOOTBOARD		1PC	E	BED SLAT		4PCS
С	RIGHT HEADBOARD LEG		1PC	F	BED SLAT SUPPORT WITH LEVELER		8PCS
B2 (BOX 2)							
G	BED RAIL		2PCS	В	212421KW(B1) FROM BOX 1 FOOTBOARD		1PC
НВ	212421KW(B1) FROM BOX 1 HEADBOARD COMPLETE		1PC			T .	

HARDWARE IDENTIFICATION


Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 212421KE (B1)

1	BOLT (M6 x 30mm - BLK)	6PCS	4	SMALL ALLEN WRENCH (M4 x 60mm - BLK)	1PC
2	LOCK WASHER (1/4" - BLK)	6PCS	5	BIG ALLEN WRENCH (M5 x 65mm - BLK)	1PC
3	FLAT WASHER (1/4"ID x 13mm - BLK)	6PCS	6	FLAT HEAD SCREW (M4 x 32mm - RBW)	8PCS

NOTE:

COASTER


ASSEMBLY INSTRUCTIONS



Note: Please take note of the marking sticker (L & R) on the headboard legs.

LOOSEN HB G B

STEP 3




PAGE 3 OF 4




ASSEMBLY INSTRUCTIONS

STEP 4




STEP 5 COMPLETE



K



Inner Size: 76.75"W X 81.00"D



Note: Dimension tolerance ± 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

212422 Nightstand

REVISION 0 : 10/16/2017 REVISION 1 : 12/26/2017 REVISION 2 : 08/09/2018 REVISION 3 : 01/02/2019 REVISION 4 : 12/13/2019

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



4PCS


HARDWARE IDENTIFICATION

1	BOLT (M6 x 50mm - BLK)	0)	4PCS
2	LOCK WASHER (1/4" - BLK)		4PCS
3	FLAT WASHER (1/4"ID x 19mm - BLK)		4PCS
4	ALLEN WRENCH (M4 x 60mm - BLK)		1PC


NOTE:

COASTER

ASSEMBLY INSTRUCTIONS STEP 1



STEP 2




STEP 3 COMPLETE







Inner Size of Drawer : 17.00"W x 12.50"D x 4.00"H x 0.25"T



Note: Dimension tolerance ± 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

212423 Dresser

REVISION 0 : 10/16/2017 REVISION 1 : 12/26/2017 REVISION 2 : 08/09/2018 REVISION 3 : 01/02/2019 REVISION 4 : 12/13/2019



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

LEG

- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



В



5 MINUTES

PARTS IDENTIFICATION

A DRESSER 1PC



C CENTER SUPPORT LEG
WITH LEVELER

1PC

HARDWARE IDENTIFICATION


1	BOLT (M6 x 50mm - BLK)	4PCS
2	LOCK WASHER (1/4" - BLK)	4PCS
3	FLAT WASHER (1/4"ID x 19mm - BLK)	4PCS
4	ALLEN WRENCH (M4 x 60mm - BLK)	1PC

NOTE:


COASTER

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



STEP 3 COMPLETE






PAGE 3 OF 3



Inner Size of Drawer: 23.25"W x 12.50"D x 5.00"H x 0.25"H



Note: Dimension tolerance ± 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

212425 Chest

REVISION 0 : 10/16/2017 REVISION 1 : 12/26/2017 REVISION 2 : 08/09/2018 REVISION 3 : 01/02/2019 REVISION 4 : 12/13/2019

COASTER

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A CHEST



1PC

B LEG



4PCS

HARDWARE IDENTIFICATION


1	BOLT (M6 x 50mm - BLK)	<u> </u>	4PCS
2	LOCK WASHER (1/4" - BLK)		4PCS
3	FLAT WASHER (1/4"ID x 19mm - BLK)		4PCS
4	ALLEN WRENCH (M4 x 60mm - BLK)		1PC

NOTE:




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



STEP 3 COMPLETE




ķ⇒ķ

PAGE 3 OF 3



Inner Size of Drawer: 23.25"W x 12.50"D x 5.00"H x 0.25"T



Note: Dimension tolerance ± 5%