


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 11/07/2018 REVISION 1 : 04/26/2019 REVISION 2 : 01/10/2020

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:215761KW (B1-B3)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING! 1. Don't attem

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ITEM:215761KW (B1-B3)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 215761KW (B1)






ITEM:215761KW (B1-B3) COASTER FINE FURNITURE **ASSEMBLY INSTRUCTIONS** STEP 3 $\widehat{\mathbf{I}}$ (\mathbf{F}) G STEP 4 COMPLETE (13)

PAGE 5 OF 5

COASTERFURNITURE.COM



COASTERFURNITURE.COM