

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222521KE(B1-B3) Eastern King Bed

REVISION 0: 08/20/2025

PAGE 1 OF 7

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Κ

WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PART IDENTIFICATION					
B1 (BOX 1)					
Α	HEADBOARD PANEL		1PC		
В	LEFT HEADBOARD LEG		1PC		
С	RIGHT HEADBOARD LEG		1PC		
D	HEADBOARD BOTTOM RAIL		1PC		
E	CONCEAL PANEL		4PCS		
<u>B2 (B</u>	3OX 2)				
F	FOOTBOARD		1PC		
B3 (BOX 3)					
G	LEFT BED RAIL		1PC		
н	RIGHT BED RAIL	MARIE	1PC		
I	ROLL SLAT (10 PCS)		1SET		

CENTER RAIL CENTER RAIL SUPPORT WITH LEVELER 222521KE(B1) *FROM BOX 1 HB **HEADBOARD COMPLETE** 222521KE(B2) *FROM BOX 2 FOOTBOARD* PAGE 2 OF 7

COASTERFURNITURE.COM

1PC

4PCS

1PC

1PC

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 222521KE(B1)

1	LONG BOLT (5/16" x 50mm - BLK)	8PCS
2	LOCK WASHER (1.6 x 14mm - BLK)	8PCS
3	FLAT WASHER (2 x 19mm - BLK)	8PCS
4	ALLEN WRENCH (M5 x 65mm - BLK)	1PC
5	WOOD DOWEL (10 x 40mm - BRW)	4PCS

Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 222521KE(B3)

2	LOCK WASHER (1.6 x 14mm - BLK)	4PCS
3	FLAT WASHER (2 x 19mm - BLK)	4PCS
6	SHORT BOLT (5/16" x 19mm - BLK)	4PCS
7	FLAT HEAD SCREW (8 x 32mm - BLK)	8PCS
8	THREADED BOLT (5/16" x 80mm - WHT)	8PCS
9	HEX NUT (5/16" x 13mm - WHT)	8PCS
10	HALF ROUND NUT (22 x 17 x 10mm - WHT)	8PCS


NOTE:

Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2







ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4









COASTER

ASSEMBLY INSTRUCTIONS

STEP 7




STEP 8 COMPLETE







Inner Size: 77.00"W x 82.00"D



Note: Dimension tolerance ±5%