



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**223061Q (B1-B3)**  
***Queen Bed***

# ITEM: 223061Q (B1-B3)



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES

## PARTS IDENTIFICATION

### B1 ( BOX 1 )

A HEADBOARD



1PC

I WOOD CAP



2PCS

B HEADBOARD POST



2PCS

### B2 ( BOX 2 )

C FOOTBOARD



1PC

E WOOD CAP



2PCS

D FOOTBOARD POST



2PCS

### B3 ( BOX 3 )

F BED RAIL



2PCS

H BED SLAT SUPPORT  
WITH LEVELER



4PCS


G BED SLAT




4PCS

HB

223061Q(B1)  
FROM BOX 1  
HEADBOARD  
COMPLETE




OR




1PC

FB

223061Q(B2)  
FROM BOX 2  
FOOTBOARD  
COMPLETE



OR



1PC

# ITEM: 223061Q (B1-B3)



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.









### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

## HARDWARE IDENTIFICATION

### Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 223061Q (B3)

1	THREADED BOLT ( $\varnothing$ 5/16" x 3" - RBW)		8PCS	2	HALF ROUND NUT ( $\varnothing$ 5/16" - RBW)		8PCS
3	LOCK WASHER ( $\varnothing$ 5/16" x 3" - RBW)		8PCS	4	HEX NUT ( $\varnothing$ 5/16" x 14MM - RBW)		8PCS
5	WRENCH (14MM - RBW)		1PC	6	FLAT HEAD SCREW ( $\varnothing$ 4 x 30MM - RBW)		8PCS

### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **223061Q (B1-B3)**




## ASSEMBLY INSTRUCTIONS


### STEP 1

#### OPTION 1

1.1




1.2




#### OPTION 2


1.1



1.2



### STEP 2




ITEM: **223061Q (B1-B3)**




## ASSEMBLY INSTRUCTIONS

### STEP 3




### STEP 4 **COMPLETE**

#### OPTION 1




#### OPTION 2



ITEM: **223061Q (B1-B3)**

**Inner Size : 61.50"W X 82.00"D**




**Note: Dimension tolerance  $\pm 5\%$**

ITEM: **223061Q (B1-B3)**



Inner Size : 61.50"W X 82.00"D



Note: Dimension tolerance  $\pm 5\%$



# ASSEMBLY INSTRUCTIONS

## COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**223062**  
***Nightstand***



ITEM: **223062**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG




4PCS

ITEM: **223062**





## ASSEMBLY INSTRUCTIONS

### STEP 1



### STEP 2 COMPLETE



ITEM: **223062**

## ANTI-TIPPING INSTALLMENT INSTRUCTIONS

### FURNITURE TIPPING RESTRAINT




#### WARNING

Injury may result from tipping furniture.  
This restraint may protect against tipping furniture.  
Do not allow children to climb on furniture.  
This restraint is not a substitute for proper adult supervision.  
Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


#### STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.





#### STEP 2

Locate the other bracket on the wall over a wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



#### STEP 3


Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.



ITEM: **223062**




**Inner Size of Drawer : 18.25"W X 13.50"D X 6.25"H X 0.50"T**



**Note: Dimension tolerance  $\pm 5\%$**

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**223063**  
**Dresser**

ITEM: **223063**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A DRESSER




1PC

B LEG



4PCS

C CENTER SUPPORT LEG  
WITH LEVELER




1PC

ITEM: **223063**




## ASSEMBLY INSTRUCTIONS

### STEP 1



### STEP 2 COMPLETE



ITEM: **223063**

## ANTI-TIPPING INSTALLMENT INSTRUCTIONS

### FURNITURE TIPPING RESTRAINT




#### WARNING

Injury may result from tipping furniture.  
This restraint may protect against tipping furniture.  
Do not allow children to climb on furniture.  
This restraint is not a substitute for proper adult supervision.  
Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


#### STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.





#### STEP 2

Locate the other bracket on the wall over a wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



#### STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.






ITEM: **223063**



Inner Size of Drawer : 26.00"W X 13.50"D X 7.75"H X 0.50"T



Note: Dimension tolerance  $\pm 5\%$

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**223064**  
***Mirror***

ITEM: **223064**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A

**DRESSER**  
FROM BOX ITEM# 223063



1PC

B


**MIRROR SUPPORT**  
(PACKED WITH DRESSER)



2PCS

C

**MIRROR**



1PC

## HARDWARE IDENTIFICATION

1

**BOLT**  
(1/4" x 38mm - RBW)



6PCS

2

**LOCK WASHER**  
(1/4" - RBW)



6PCS

3


**FLAT WASHER**  
(1/4" - RBW)



6PCS

4

**ALLEN WRENCH**  
(4mm - RBW)




1PC

ITEM: **223064**




## ASSEMBLY INSTRUCTIONS


### STEP 1



### STEP 2 COMPLETE



ITEM: **223064**



**Note: Dimension tolerance  $\pm 5\%$**

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**223065**  
**Chest**

ITEM: **223065**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A

CHEST



1PC

B

LEG




4PCS

ITEM: **223065**





## ASSEMBLY INSTRUCTIONS

### STEP 1



### STEP 2 COMPLETE





ITEM: **223065**



## ANTI-TIPPING INSTALLMENT INSTRUCTIONS

### FURNITURE TIPPING RESTRAINT

#### WARNING

Injury may result from tipping furniture.




This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
7. To double lock return the beaded end back through the keyhole as shown.
8. Check to make sure the cable tie is securely laced and locked to the brackets.




ITEM: **223065**



Inner Size of Drawer A : 28.25"W X 13.50"D X 5.25"H X 0.50"T

Inner Size of Drawer B : 28.25"W X 13.50"D X 7.25"H X 0.50"T



**Note: Dimension tolerance  $\pm 5\%$**