


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223091NVYQ Queen Bed

ITEM:223091NVYQ

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

Α	HEADBOARD PANEL	1PC	F	BED RAIL (WITH "F"LABEL)	2PCS
В	LEFT HEADBOARD LEG	1PC	G	BED RAIL SUPPORT	2PCS
С	RIGHT HEADBOARD LEG	1PC	н	BED SLAT	4PCS
D	FOOTBOARD	1PC	ı	BED SLAT SUPPORT WITH LEVELER	4PCS
Е	BED RAIL (WITH "E"LABEL)	2PCS			

HARDWARE IDENTIFICATION

1	BOLT 1 (M8 x 20MM - RBW)		8PCS	6	FLAT WASHER (1/4" x 19 Ø - RBW)	14PCS
2	BOLT 2 (M6 x 30MM - RBW)		8PCS	7	FLAT HEAD SCREW (M4 x 32MM - RBW)	8PCS
3	BOLT 3 (M6 x 35MM - RBW)		4PCS	8	SMALL ALLEN WRENCH (M4 x 100MM - BLK)	1PC
4	BOLT 4 (M6 x 50MM - RBW)	0	6PCS	9	BIG ALLEN WRENCH (M5 x 65MM - BLK)	1PC
5	LOCK WASHER (1/4" x 12 Ø - RBW)		14PCS			


NOTE:

ITEM: 223091NVYQ


COASTER

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: 223091NVYQ

COASTER


COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS


STEP 3




STEP 4



PAGE 4 OF 5






ITEM: 223091NVYQ



Inner Size: 60.75"W x 81.00"D





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223092 Nightstand

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION


A	NIGHTSTAND	1PC
Y1	HANDLE A WITH SCREW	1SET
Y2	HANDLE B WITH SCREW	1SET

NOTE:


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1




STEP 2 COMPLETE







Inner Size of Drawer: 18.25"W X 12.50"D X 5.00"H X 0.50"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223093 Dresser

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER

1PC

Y1 HANDLE A WITH SCREW

3SETS


3SETS

NOTE:


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1



STEP 2 COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be placing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer: 25.25"W X 12.25"D X 5.00"H X 0.50"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223094 *Mirror*

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR


B MIRROR SUPPORT (PACKED WITH MIRROR)


C DRESSER *FROM BOX ITEM 223093

HARDWARE IDENTIFICATION


1	BOLT (M6 x 40MM - RBW)	8PCS
2	LOCK WASHER (1/4" x 13Ø - RBW)	8PCS
3	FLAT WASHER (1/4" x 19Ø - RBW)	8PCS
4	ALLEN WRENCH (M4 x 110MM - BLK)	1PC

NOTE:









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223095 Chest

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION


A	CHEST	1PC
Y1	HANDLE A WITH SCREW	3SETS
Y2	HANDLE B WITH SCREW	2SETS

NOTE:


ASSEMBLY INSTRUCTIONS

STEP 1





STEP 2 COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be placing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer: 28.00"W X 12.25"D X 5.00"H X 0.50"T



Note: Dimension tolerance ±5%