

Fine Furniture for every stage of life

223441KE (B1&B2) Eastern King Bed

REVISION 0:09/05/2024

PAGE 1 OF 6

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	HEADBOARD PANEL	1PC	E	LEFT FOOTBOARD LEG (WITH "L" LABEL)		1PC
В	LEFT HEADBOARD LEG (WITH "L" LABEL)	1PC	F	RIGHT FOOTBOARD LEG (WITH "R" LABEL)	○	1PC
С	RIGHT HEADBOARD LEG (WITH "R" LABEL)	1PC	G	BED SLAT		4PCS
D	FOOTBOARD PANEL	1PC	н	BED SLAT SUPPORT WITH LEVELER		8PCS

B2 (BOX 2)

I BED RAIL



PCS

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE IS LOCATED IN 223441KE (B1)

1	SHORT BOLT (M8 x 16MM - RBW)	8PCS	6	SMALL LOCK WASHEI (1/4" x 13Ø - RBW)	R	4PCS
2	MEDIUM BOLT (M8 x 35MM - RBW)	6PCS	7	SMALL FLAT WASHER (1/4" x 19Ø - RBW)	R	4PCS
3	BIG LOCK WASHER (5/16" x 14Ø - RBW)	6PCS	8	FLAT HEAD SCREW (M4 x 32MM - RBW)	(-	8PCS
4	BIG FLAT WASHER (5/16" x 22Ø - RBW)	6PCS	9	BIG ALLEN WRENCH (M5 x 68MM - BLK)		1PC
5	LONG BOLT (M6 x 40MM - RBW)	4PCS	10	SMALL ALLEN WRENCH (M4 x 60MM - BLK)		1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.




COASTER

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




** BACK VIEW

PAGE 4 OF 6


COASTER

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ASSEMBLY INSTRUCTIONS

STEP 5





STEP 6 COMPLETE






PAGE 6 OF 6



Inner Size: 76.50"W X 81.00"D



Note: Dimension tolerance ±5%





Fine Furniture for every stage of life

223442 Nightstand

REVISION 0: 09/05/2024

PAGE 1 OF 3

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



4PCS

HARDWARE IDENTIFICATION

1	BOLT (M6 x 40MM - RBW)	4PCS
2	LOCK WASHER (1/4" x 13Ø - RBW)	4PCS
3	FLAT WASHER (1/4" x 19Ø - RBW)	4PCS
4	WOOD DOWEL (Ø8 x 30MM)	4PCS
5	ALLEN WRENCH (M4 x 110MM - BLK)	1PC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1




STEP 2 COMPLETE







Inner Size of Drawer : 13.50"W x 12.25"D x 5.00"H x 0.50"T



Note: Dimension tolerance ± 5%





Fine Furniture for every stage of life

223443 Dresser

REVISION 0: 09/05/2024

PAGE 1 OF 4

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER



1PC

B LEG



4PCS

C CENTER LEG SUPPORT WITH LEVELER



1PC

HARDWARE IDENTIFICATION

1	BOLT	4PCS
•	(M6 x 40MM - RBW)	4600

•	LOCK WASHER	4DCC
2	(4/4" v 120 DDM)	4PCS

•	FLAT WASHER	4000
3	(1/4" x 19Ø - RBW)	4PCS

4	WOOD DOWEL	4000
4	(Ø8 x 30MM)	4PCS

5	ALLEN WRENCH	100
3	(M4 x 110MM - BLK)	IFC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1



STEP 2 COMPLETE





ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be placing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.











Inner Size of Drawer: 23.00"W x 12.25"D x 5.00"H x 0.50"T



Note: Dimension tolerance ± 5%





Fine Furniture for every stage of life

223444 Mirror

REVISION 0:09/05/2024

PAGE 1 OF 3

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

DRESSER

***FROM BOX ITEM 223443**

- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



C

ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

B MIRROR SUPPORT (PACKED WITH MIRROR)

2PCS

HARDWARE IDENTIFICATION

1	BOLT (M6 x 40MM - RBW)	8PCS
2	LOCK WASHER (1/4" x 13Ø - RBW)	8PCS
3	FLAT WASHER (1/4" x 19Ø - RBW)	8PCS
4	ALLEN WRENCH (M4 x 110MM - BLK)	1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.

1PC


ASSEMBLY INSTRUCTIONS

COASTER

STEP 1




STEP 2 COMPLETE









Note: Dimension tolerance ± 5%