COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

224331Q (B1-B3)
Queen Bed

ITEM: 224331Q (B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	25 MINUTES

PART IDENTIFICATION

B1 (BOX 1)

A	HEADBOARD PANEL		1PC
B	LEFT HEADBOARD LEG		1PC
C	RIGHT HEADBOARD LEG		1PC
D	HEADBOARD BOTTOM RAIL		1PC

B2 (BOX 2)

E	FOOTBOARD		1PC

B3 (BOX 3)

F	BED RAIL		2PCS
G	BED SLAT		4PCS
H	BED SLAT SUPPORT WITH LEVELER		4PCS
HB	224331Q(B1) *FROM BOX 1 HEADBOARD COMPLETE		1PC
E	224331Q(B2) *FROM BOX 2 FOOTBOARD		1PC

ITEM: 224331Q (B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 224331Q (B1)

1	**BOLT** (5/16" x 45mm - BLK)		8PCS
2	**LOCK WASHER** (1.6 x 14mm - BLK)		8PCS
3	**FLAT WASHER** (1 x 18mm - BLK)		8PCS
4	**ALLEN WRENCH** (M5 x 65mm - BLK)		1PC
5	**WOOD DOWEL** (10 x 30mm - BRW)		4PCS

Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 224331Q (B3)

6	**FLAT HEAD SCREW** (8 x 38mm - BLK)		8PCS
7	**THREADED BOLT** (5/16" x 80mm - WHT)		8PCS
8	**HEX NUT** (5/16" x 100mm - WHT)		8PCS
9	**HALF ROUND NUT** (22 x 17 x 10mm - WHT)		8PCS
10	**WRENCH** (13mm - WHT)		1PC

NOTE :

Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 224331Q (B1-B3)

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



ITEM: 224331Q (B1-B3)

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4



ITEM: 224331Q (B1-B3)

ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6
COMPLETE



ITEM: 224331Q (B1-B3)

Inner Size : 61.00”W x 82.00”D



Note: Dimension tolerance ±5%

COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

224332
Nightstand

REVISION 0 : 10/25/2023
REVISION 1 : 04/17/2024

ITEM: **224332**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME	10 MINUTES

PART IDENTIFICATION

A	NIGHTSTAND		1PC
B	LEFT METAL LEG		1PC
C	RIGHT METAL LEG		1PC

HARDWARE IDENTIFICATION

1	BOLT (M6 x 22mm - BLK)		6PCS
2	LOCK WASHER (1.6 x 14mm - BLK)		6PCS
3	FLAT WASHER (1 x 18mm - BLK)		6PCS
4	ALLEN WRENCH (M4 x 65mm - BLK)		1PC

ITEM: **224332**

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2

COMPLETE



ITEM: **224332**

ANTI-TIPPING INSTALLATION INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
4. Attach the bracket over the plastic wall anchor using the long screw.
5. Place the unit against the wall, both brackets need to be facing each other.
6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
7. Ensure that the restraint strap is securely laced and locked.





ITEM: **224332**

Inner Size of Drawer A : 18.75”W x 13.75”D x 3.50”H x 0.5”T
Inner Size of Drawer B : 18.75”W x 13.75”D x 6.00”H x 0.5”T



Note: Dimension tolerance ±5%

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

224333
Dresser

REVISION 0 : 10/25/2023
REVISION 1 : 04/17/2024

ITEM: **224333**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	10 MINUTES

PART IDENTIFICATION

A	DRESSER		1PC
B	LEFT METAL LEG		1PC
C	RIGHT METAL LEG		1PC
D	CENTER SUPPORT LEG WITH LEVELER		1PC

HARDWARE IDENTIFICATION

1	BOLT (M6 x 22mm - BLK)		6PCS
2	LOCK WASHER (1.6 x 14mm - BLK)		6PCS
3	FLAT WASHER (1 x 18mm - BLK)		6PCS
4	ALLEN WRENCH (M4 x 65mm - BLK)		1PC

ITEM: **224333**

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2

COMPLETE

224333

ANTI-TIPPING INSTALLATION INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
4. Attach the bracket over the plastic wall anchor using the long screw.
5. Place the unit against the wall, both brackets need to be facing each other.
6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
7. Ensure that the restraint strap is securely laced and locked.





ITEM: **224333**

Inner Size of Drawer A : 26.50”W x 13.75”D x 3.50”H x 0.5”T
Inner Size of Drawer B : 26.50”W x 13.75”D x 6.50”H x 0.5”T



Note: Dimension tolerance ±5%

COASTER
FINE FURNITURE

INSTRUCTIONS D'ASSEMBLAGE
COASTER FINE FURNITURE

Fine Furniture for every stage of life

224334
Mirror

ITEM: 224334

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	15 MINUTES

PART IDENTIFICATION

A	DRESSER *FROM BOX ITEM 224333*		1 PC
B	MIRROR		1 PC
C	MIRROR SUPPORT (PACKED WITH MIRROR)		1 PC
D	JEWELRY TRAY (PACKED WITH MIRROR)		1 PC

HARDWARE IDENTIFICATION

1	METAL CONNECTING MIRROR (2.5 x 65 x 65mm - BLK)		2 PCS
2	BOLT (M6 x 22mm - BLK)		4 PCS
3	BOLT (M6 x 45mm - BLK)		4 PCS
4	LOCK WASHER (1.6 x 14mm - BLK)		4 PCS
5	FLAT WASHER (1 x 18mm - BLK)		4 PCS
6	ALLEN WRENCH (M4 x 65mm - BLK)		1 PC

ITEM: **224334**

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2



ITEM: **224334**

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4
COMPLETE



ITEM: **224334**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	15 MINUTES

PART IDENTIFICATION

B	MIRROR		1 PC
E	SHORT HANGING BAR (PACKED WITH MIRROR)		1 PC
F	LONG HANGING BAR (PACKED WITH MIRROR)		2 PCS

HARDWARE IDENTIFICATION

7	FLAT HEAD SCREW (8 x 1" - BLK)		2 PCS
8	SHORT PAN HEAD SCREW (8 x 5/8" - BLK)		6 PCS
9	LONG PAN HEAD SCREW (8 x 2" - BLK)		6 PCS
10	PLASTIC ANCHOR (S8 - GREY)		6 PCS

ITEM: **224334**

ASSEMBLY INSTRUCTIONS

STEP 1
FOR HANGING MIRROR



STEP 2
FOR HANGING MIRROR



ITEM: **224334**

ASSEMBLY INSTRUCTIONS

STEP 3
FOR HANGING MIRROR COMPLETE





ITEM: **224334**



Note: Dimension tolerance ±5%