COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

224337
Makeup Desk

REVISION 0 : 10/25/2023
REVISION 1 : 03/02/2026

ITEM: **224337**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME	15 MINUTES

PART IDENTIFICATION

A	TOP		1PC
B	FRONT LEG		2PCS
C	LEFT BACK LEG		1PC
D	RIGHT BACK LEG		1PC
E	SHORT METAL STRETCHER		2PCS
F	LONG METAL STRETCHER		1PC


HARDWARE IDENTIFICATION

1	BOLT (M6 x 35mm - BLK)		8PCS
2	LOCK WASHER (1.6 x 14mm - BLK)		8PCS
3	FLAT WASHER (1 x 18mm - BLK)		8PCS
4	ALLEN WRENCH (M4 x 65mm - BLK)		1PC
5	FLAT HEAD SCREW (8 x 2" - BLK)		6PCS


ITEM: **224337**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **224337**

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4
COMPLETE



ITEM: **224337**

COASTER FINE FURNITURE

Inner Size of Drawer : 16.50”W x 13.75”D x 2.00”H x 0.5”T



NOTE: Dimension tolerance ± 5%