

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

2388 DINING TABLE

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A LEG 4PCS


B TABLE TOP 1PCS

HARDWARE IDENTIFICATION


1	(1/4" x 38mm)	12PCS
2	JUNCTION PIECE	2PCS
3	END CAP (1-1/4")	10PCS
4	LEVELER (1/4")	4PCS
5	WRENCH (4mm)	1PC



ASSEMBLY INSTRUCTIONS STEP 1



STEP 2




PAGE 3 OF 5



ASSEMBLY INSTRUCTIONS STEP 3
COMPLETE







Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

2450R SIDE CHAIR

REVISION 0: 05/20/2018 REVISION 1: 07/29/2019 REVISION 2: 07/23/2020 REVISION 3: 08/25/2022 REVISION 4: 03/13/2023 REVISION 5: 11/15/2023 REVISION 6: 07/05/2024

REVISION 7:07/23/2025

PAGE 1 OF 4

ITEM: 2450R

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



10 MINUTES

PARTS IDENTIFICATION

Α	FRONT LEFT LEG FRAME	H	1 PC
В	FRONT RIGHT LEG FRAME		1 PC
С	BACK LEG FRAME		1 PC
D	BACK CUSHION		1 PC
E	SEAT CUSHION		1 PC
Z	HARDWARE I	DENTIFICATION	
1	BOLT (1/4" x 41mm)		8 PCS
2			8 PCS
	(1/4" x 41mm) SCREW		

NOTE:

QUANTITIES SHOWN ARE FOR ONE CHAIR


Phillips head screw driver is required in the assembly process; however,manufacturer does not provide this item.

PAGE 2 OF 4


ITEM: **2450R**

COASTER


ASSEMBLY INSTRUCTIONS STEP 1



STEP 2



STEP 3




STEP 4
COMPLETE



PAGE 3 OF 4

ITEM: **2450R**





Note: Dimension tolerance ±5%