



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

300644
Ottoman

REVISION 0: 01/17/2017
REVISION 1: 08/14/2018
REVISION 2: 08/20/2018
REVISION 3: 08/27/2019

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: **300644**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A OTTOMAN



1PC


B LEG



4PCS

HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW
(Φ4 X 20mm - RBW)



12PCS

2 FLAT WASHER
(Φ7 X 13 X 1mm - RBW)



12PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **300644**




ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2 COMPLETE



ITEM:300644



Note : Dimension tolerance $\pm 5\%$