

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204392 Nightstand

REVISION 0 : 10/30/2015 REVISION 1 : 01/21/2020

#### **ASSEMBLY INSTRUCTIONS**



- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

## $\Lambda$

#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

#### **PARTS IDENTIFICATION**

A NIGHTSTAND

1PC

D RIGHT BACK LEG (WITH BR LABEL)

1PC

B RIGHT FRONT LEG (WITH FR LABEL)

1PC

C LEFT FRONT LEG (WITH FL LABEL)

1PC

#### HARDWARE IDENTIFICATION

1 BOLT (M6 x 35mm - BLK) 8PCS 3 FLAT WASHER (1/4" x 20mm - BLK) 8PCS
2 LOCK WASHER (1/4" - BLK) 8PCS 4 ALLEN WRENCH (M4 x 65mm - BLK) 1PC


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


#### **ASSEMBLY INSTRUCTIONS**



#### STEP 1




#### STEP 2



#### **ASSEMBLY INSTRUCTIONS**

## COASTER FINE FURNITURE


STEP 3
COMPLETE







Inner Size Of Drawer: 12.75"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**204393** *Dresser* 

REVISION 0 : 10/30/2015 REVISION 1 : 01/21/2020 REVISION 2 : 09/14/2024

PAGE 1 OF 6

#### **ASSEMBLY INSTRUCTIONS**

## COASTER

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

#### **PARTS IDENTIFICATION**

A	DRESSER	1PC	D RIGHT BACK LEG (WITH BR LABEL)	1PC
В	RIGHT FRONT LEG (WITH FR LABEL)	1PC	E LEFT BACK LEG (WITH BL LABEL)	1PC
С	LEFT FRONT LEG (WITH FL LABEL)	1PC	F SUPPORT LEG	1PC

#### **HARDWARE IDENTIFICATION**

1	BOLT (M6 x 35mm - BLK)		8PCS	3 FLAT WASHER (1/4" x 20mm - BLK)	0	8PCS
2	LOCK WASHER (1/4" - BLK)	<b>©</b>	8PCS	4 ALLEN WRENCH (M4 x 65mm - BLK)		1PC


#### NOTE:

Philips head screw driver in the assembly process; however, manufacturer does not provide the item


#### ITEM: **204393 ASSEMBLY INSTRUCTIONS**



#### STEP 1



#### STEP 2



# ITEM: **204393 ASSEMBLY INSTRUCTIONS**

## COASTER

STEP 3
COMPLETE







#### ANTI-TIPPING INSTALLATION INSTRUCTIONS **FURNITURE TIPPING RESTRAINT**

#### WARNING


Injury may result from tipping furniture. This restraint may protect against tipping furniture. Do not allow children to climb on furniture. This restraint is not a substitle for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


#### STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.




#### STEP 2

Locate the wood stud on the wall and secure the other bracket 2 inches below the back of the unit, using the long screw.



#### STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the threaded end of the restraint strap through the hole in each mounting bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight. Ensure that the restraint strap is securely laced and locked.








PAGE 5 OF 6 COASTERFURNITURE.COM



Inner Size Of Drawer: 23.25"W X 12.75"D X 5.00"H X 0.25"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204394 *Mirror* 

REVISION 0 : 06/17/2015 REVISION 1 : 06/24/2016 REVISION 2 : 01/21/2020

#### **ASSEMBLY INSTRUCTIONS**

## COASTER

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

#### PARTS IDENTIFICATION

A MIRROR 1PC

B MIRROR SUPPORT (PACKAGED WITH DRESSER)

C DRESSER FROM BOX ITEM#204393

#### **HARDWARE IDENTIFICATION**

1 PAN HEAD SCREW
(M4 X32mm - BLK)

#### NOTE:


Philips head screw driver in the assembly process; however, manufacturer does not provide the item

8PCS


## COASTER

#### **ASSEMBLY INSTRUCTIONS**

#### STEP 1




#### STEP 2




# ITEM: 204394 ASSEMBLY INSTRUCTIONS STEP 3 COMPLETE












Note: Dimension tolerance  $\pm 5\%$ 



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

300762KE Eastern King Bed





#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

#### PARTS IDENTIFICATION

Α	HEADBOARD PANEL	1PC	F	BED RAIL (WITH "F" LABEL)	2PCS
В	LEFT HEADBOARD LEG (WITH "L" LABEL)	1PC	G	BED RAIL (WITH "G" LABEL)	2PCS
С	RIGHT HEADBOARD LEG (WITH "R" LABEL)	1PC	н	BED RAIL SUPPORT LEG	2PCS
D	FOOTBOARD PANEL	1PC	I	BED SLAT	4PCS
E	FOOTBOARD LEG	2PCS	J	BED SLAT SUPPORT WITH LEVELER	8PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.





#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

#### HARDWARE IDENTIFICATION

1	BOLT 1 (M8 x 20mm - RBW)	<b>1</b>	8PCS	6	LOCK WASHER (1/4" X 12 Ø - RBW)		14PCS
2	BOLT 2 (M6 x 25mm - RBW)		8PCS	7	FLAT WASHER (1/4" X 19 Ø - RBW)	0	14PCS
3	BOLT 3 (M6 x 35mm - RBW)		14PCS	8	FLAT HEAD SCREW (M4 x 32mm - RBW)		8PCS
4	BOLT 4 (M6 x 70mm - RBW)	(M)====================================	2PCS	9	SMALL ALLEN WRENCH (M4 x 100mm - BLK)		1PC
5	WOOD DOWEL (M8Ø x 30mm)		2PCS	10	BIG ALLEN WRENCH (M5 x 65mm - BLK)		1PC


#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.


## COASTER

#### **ASSEMBLY INSTRUCTIONS**

#### STEP 1




#### STEP 2




#### **ASSEMBLY INSTRUCTIONS**

#### STEP 3



#### STEP 4




PAGE 5 OF 6




COASTERFURNITURE.COM

#### **ASSEMBLY INSTRUCTIONS**

#### STEP 5




## STEP 6



PAGE 6 OF 6



Inner Size: 76.50"W X 81.00"D



Note: Dimension tolerance ± 5%