

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

301392 Night Stand

REVISION 0: 26/04/2019 REVISION 1: 17/08/2023

PAGE 1 OF 5 COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Λ

WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION




HARDWARE IDENTIFICATION

1	BOLT (1/4"X1/2" - BLK)	4PCS	3	SUCTION CUP	4PCS
2	BOLT (1/4"x1-3/4" - BLK)	4PCS	4	ALLEN WRENCH (4x4mm -BLK)	1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.






ASSEMBLY INSTRUCTIONS STEP 1:


ASSEMBLY


Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.





COASTERFURNITURE.COM





PAGE 4 OF 5


ASSEMBLY INSTRUCTIONS STEP 3:









4PCS






STEP 4:



COASTERFURNITURE.COM





Note: Dimension tolerance ±5%