



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

316028BLKT
Twin Bed

ITEM: **316028BLKT**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A HEADBOARD AND FOOTBOARD



2PCS

B BED RAIL



2PCS

C LEG WITH LABEL "C"



2PCS

D LEG WITH LABEL "D"



2PCS

E ROLL SLAT (17 PCS)



1SET

F CENTER RAIL



1PC

G CENTER RAIL SUPPORT WITH LEVELER



3PCS

HARDWARE IDENTIFICATION

1 THUMB BOLT (M6 x 50mm - BLK)



8PCS

2 FLAT HEAD SCREW (M4 x 25mm - BLK)



10PCS

NOTE :


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 316028BLKT


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: 316028BLKT


ASSEMBLY INSTRUCTIONS



STEP 3




STEP 4





ITEM: **316028BLKT**
ASSEMBLY INSTRUCTIONS



STEP 5




STEP 6
COMPLETE



ITEM: **316028BLKT**



Inner Size: 39.50"W X 77.00"D



Note : Dimension tolerance $\pm 5\%$