


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

405050GRY
Extension Kit

ITEM : 405050GRY

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly



WARNING! :

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION


A TOP PANEL 1PC




B CENTER RAIL 1PC



C LEFT PANEL 1PC



D RIGHT PANEL 1PC



TT 405051GRY(B1&B2)



1SET

OR

TT 405053GRY(B1&B2)



1SET

HARDWARE IDENTIFICATION

1 LONG BOLT (M6 x 80mm - BLK) 8PCS



2 SHORT BOLT (M6 x 30mm - BLK) 4PCS



3 FLAT HEAD SCREW (M3.5 x 16mm - BLK) 12PCS



4 WOOD DOWEL (Ø10 x 30mm) 8PCS



5 BARREL NUT (M6 x 13mm - RBW) 8PCS



6 METAL BRACKET (BLK) 3PCS



7 ALLEN WRENCH (M4 - BLK) 1PC



NOTE:


Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM : **405050GRY**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM : **405050GRY**




ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM : **405050GRY**

ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6




FROM 405051GRYB2 (BOX 2)
OR 405053GRYB2 (BOX 2)


ITEM : **405050GRY**

ASSEMBLY INSTRUCTIONS

STEP 7




STEP 8




ITEM : **405050GRY**

ASSEMBLY INSTRUCTIONS

STEP 9



STEP 10 **COMPLETE**



ITEM : 405051GRY (B1&B2) & 405050GRY/ 405053GRY (B1&B2) & 405050GRY



ASSEMBLY INSTRUCTIONS

SIZE OF MATTRESS

The length and width of the bunk mattress are as follow :

	<u>Length</u>	<u>Width</u>	<u>Thickness</u>
Upper bunk	74" - 75"	37 1/2" - 38 1/2"	6" Maximum
Lower bunk	74" - 75"	53" - 54"	6" Maximum

Ensure thickness of mattress does not exceed 6" and there must be at least 5" from mattress sleeping surface to top edge of guardrail.



SAFETY WARNING



1. Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed.
2. Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls.
3. Surface of mattress must be at least 5 in. (127 mm) below the upper edge of guardrails.
4. Do not allow children under 6 years of age to use the upper bunk.
5. Prohibit more than one person on upper bunk.
6. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
7. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
8. Always use the ladder for entering and leaving the upper bunk.
9. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
10. Use of a night light may provide added safety precaution for a child using the upper bunk.
11. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
12. The use of water or sleep flotation mattresses is prohibited.
13. Keep these instructions for future reference.

STRANGULATION HAZARD

14. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to hooks, belts and jump ropes.

REPLACEMENT PART :

Replacement part, including additional guardrails may be obtained from any COASTER Furniture Dealer.

ITEM : **405051GRY (B1&B2) & 405050GRY/
405053GRY (B1&B2) & 405050GRY**

ASSEMBLY INSTRUCTIONS

 **WARNING** 
TO PREVENT SERIOUS OR FATAL INJURY

1. When using beds as bunk beds, the ladder **MUST** be securely attached to the upper bunk rail at all times.
2. When using the beds as two (2) separate floor-standing beds, the ladder **MUST** be stored in a separate location where children cannot use the ladder in any manner.
3. **DO NOT** use, nor permit children to use, the ladder in any manner whatsoever, other than to access the top unit when used as bunk beds, and only if the ladder is securely attached to the top bunk rail, as set forth in the instructions.
4. Any misuse or unauthorized use of the ladder could result in serious or fatal injury.
5. Failure to follow the above **WARNING**, and/or failure to follow assembly instructions completely, will void any and all liability of **COASTER COMPANY OF AMERICA** for damages and injury to persons and property.



Coasterfurniture.com | 877- COASTER (262-7837)

Technical drawing of a wooden bunk bed with dimensions. The drawing shows a side view of the bed with a ladder and a storage drawer. Dimensions are provided in inches.

Dimensions:

- Overall height: 64.00"
- Overall width: 76.00"
- Overall depth: 79.25"
- Top bunk height: 48.00"
- Top bunk width: 38.25"
- Top bunk depth: 13.50"
- Bottom bunk height: 16.00"
- Bottom bunk width: 12.00"
- Bottom bunk depth: 12.00"
- Ladder height: 11.25"
- Ladder width: 9.75"
- Ladder depth: 12.00"
- Ladder width: 12.00"
- Ladder width: 7.75"
- Storage drawer height: 20.75"
- Storage drawer width: 12.00"
- Storage drawer depth: 12.00"
- Storage drawer width: 12.75"
- Storage drawer width: 17.25"
- Storage drawer width: 15.75"
- Storage drawer width: 37.00"
- Storage drawer width: 42.00"
- Storage drawer width: 72.25"
- Storage drawer width: 56.75"

COASTERFURNITURE.COM

TWIN/FULL BUNK BED



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

405051GRY(B1&B2)
Twin/Twin Bunk Bed

ITEM : 405051GRY (B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly



WARNING! :

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

45 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	LEFT FRONT & RIGHT BACK LOWER BED END LEG		2PCS
B	LEFT BACK & RIGHT FRONT LOWER BED END LEG		2PCS
C	LEFT FRONT & RIGHT BACK UPPER BED END LEG		2PCS
D	LEFT BACK UPPER BED END LEG		1PC
E	RIGHT FRONT UPPER BED END LEG		1PC
F	LOWER BED END & LEFT UPPER BED END		3PCS
G	RIGHT UPPER BED END (WITH "G" LABEL)		1PC

ITEM : 405051GRY (B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly



WARNING! :

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

PARTS IDENTIFICATION

B2 (BOX 2)

H	LOWER SIDE RAIL		2PCS
I	FRONT UPPER SIDE RAIL		1PC
J	BACK UPPER SIDE RAIL		1PC
K	BACK GUARD RAIL		2PCS
L	FRONT GUARD RAIL		2PCS
M	GUARD RAIL SUPPORT		3PCS
N	ROLL SLAT (13PCS)		2SETS
O	LEFT LADDER STILE		1PC
P	RIGHT LADDER STILE		1PC
Q	LADDER STEP		4PCS

ITEM : 405051GRY (B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly






WARNING! :

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 405051GRY (B1)

1	BOLT 4 (M6 x 100mm - BLK)		16PCS
2	BOLT 3 (M6 x 80mm - BLK)		22PCS
3	BOLT 2 (M6 x 60mm - BLK)		8PCS
4	BOLT 1 (M6 x 30mm - BLK)		6PCS
5	HEX HEAD SCREW (M6 x 28mm - BLK)		16PCS
6	LONG FLAT HEAD SCREW (M4 x 28mm - BLK)		48PCS
7	SHORT FLAT HEAD SCREW (M3.5 x 16mm - BLK)		2PCS
8	WOOD DOWEL (Ø10 x 30mm)		36PCS
9	BARREL NUT (M6 x 13mm - RBW)		46PCS
10	METAL PIN (Ø9.5 x 127mm - RBW)		4PCS
11	ALLEN WRENCH (M4 - BLK)		1PC

NOTE:


Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM : 405051GRY (B1&B2)




ASSEMBLY INSTRUCTIONS LOWER BED END

STEP 1



STEP 2




ITEM : 405051GRY (B1&B2)




ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4



UPPER BED END


STEP 5




ITEM : 405051GRY (B1&B2)

ASSEMBLY INSTRUCTIONS

STEP 6




STEP 7




ITEM : 405051GRY (B1&B2)

ASSEMBLY INSTRUCTIONS


STEP 8



STEP 9



STEP 10




ITEM : 405051GRY (B1&B2)




ASSEMBLY INSTRUCTIONS


STEP 11



STEP 12 COMPLETE



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

405050GRY
Extension Kit

ITEM : 405050GRY

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly



WARNING! :





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL		1PC	TT	405051GRY(B1&B2)		1SET
B	CENTER RAIL		1PC				
C	LEFT PANEL		1PC				
D	RIGHT PANEL		1PC				

HARDWARE IDENTIFICATION

1	LONG BOLT (M6 x 80mm - BLK)		8PCS	5	BARREL NUT (M6 x 13mm - RBW)		8PCS
2	SHORT BOLT (M6 x 28mm - BLK)		4PCS	6	METAL BRACKET (BLK)		3PCS
3	FLAT HEAD SCREW (M3.5 x 16mm - BLK)		12PCS	7	ALLEN WRENCH (M4 - BLK)		1PC
4	WOOD DOWEL (Ø10 x 30mm)		8PCS				

NOTE:


Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM : **405050GRY**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM : **405050GRY**




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM : **405050GRY**




ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6




ITEM : **405050GRY**

ASSEMBLY INSTRUCTIONS

STEP 7



STEP 8




ITEM : **405050GRY**




ASSEMBLY INSTRUCTIONS

STEP 9



STEP 10 COMPLETE



ASSEMBLY INSTRUCTIONS

SIZE OF MATTRESS

The length and width of the bunk mattress are as follow :

	<u>Length</u>	<u>Width</u>	<u>Thickness</u>
Upper bunk	74" - 75"	37 1/2" - 38 1/2"	6" Maximum
Lower bunk	74" - 75"	53" - 54"	6" Maximum

Ensure thickness of mattress does not exceed 6" and there must be at least 5" from mattress sleeping surface to top edge of guardrail.



SAFETY WARNING



1. Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed.
2. Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls.
3. Surface of mattress must be at least 5 in. (127 mm) below the upper edge of guardrails.
4. Do not allow children under 6 years of age to use the upper bunk.
5. Prohibit more than one person on upper bunk.
6. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
7. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
8. Always use the ladder for entering and leaving the upper bunk.
9. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
10. Use of a night light may provide added safety precaution for a child using the upper bunk.
11. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
12. The use of water or sleep flotation mattresses is prohibited.
13. Keep these instructions for future reference.

STRANGULATION HAZARD

14. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to hooks, belts and jump ropes.

REPLACEMENT PART :

Replacement part, including additional guardrails may be obtained from any COASTER Furniture Dealer.

ASSEMBLY INSTRUCTIONS

WARNING TO PREVENT SERIOUS OR FATAL INJURY

1. When using beds as bunk beds, the ladder **MUST** be securely attached to the upper bunk rail at all times.
2. When using the beds as two (2) separate floor-standing beds, the ladder **MUST** be stored in a separate location where children cannot use the ladder in any manner.
3. **DO NOT** use, nor permit children to use, the ladder in any manner whatsoever, other than to access the top unit when used as bunk beds, and only if the ladder is securely attached to the top bunk rail, as set forth in the instructions.
4. Any misuse or unauthorized use of the ladder could result in serious or fatal injury.
5. Failure to follow the above WARNING, and/or failure to follow assembly instructions completely, will void any and all liability of COASTER COMPANY OF AMERICA for damages and injury to persons and property.




Coasterfurniture.com | 877- COASTER (262-7837)

ITEM : **405051GRY (B1&B2) & 405050GRY**
TWIN/FULL BUNK BED



Inner Size (Upper) : 76.00"W X 38.75"D
Inner Size (Lower) : 76.00"W X 54.00"D



Note : Dimension tolerance $\pm 5\%$