



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

503991

SECTIONAL 2 PC SET

ITEM: 503991



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

3 MINUTES

PARTS IDENTIFICATION

503991B1(BOX 1)

A LEFT SIDE SOFA



1 PC

B RUST PILLOW



1PC

C EBONY & WHITE PILLOW



1PC

503991B2(BOX 2)

D RIGHT SIDE SOFA



1 PC

B RUST PILLOW



1PC

E PEARL GREY PILLOW





1PC



503991B1



503991B2




ITEM: 503991



ASSEMBLY INSTRUCTIONS

PRODUCT DIMENSION



Note: Dimension tolerance $\pm 5\%$

