


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



506803 CHAIR

ITEM: 506803

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

8 MINUTES

PARTS IDENTIFICATION

	PART NAME	FIGURE	QUANTITY
A	CHAIR		1PC
В	BACK CUSHION		1PC
С	SEAT CUSHION		1PC
D	LEGS		4PCS


HARDWARE IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
1	BOLT 8*60mm		8PCS
2	FLAT WSAHER 8*18mm		8PCS
3	Allen wrench M8		1PC

ITEM: 506803

ASSEMBLY INSTRUCTIONS STEP 1








D












STEP 3



www.coastercompany.com

PAGE 3 OF 4

