



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**508461
SOFA**

ITEM : 508461



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT
1PC



B LEG
4PC



C MIDDLE LEG
1PC



D PILLOW
2PCS




ITEM : 508461


ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE



STEP 1



STEP 2




STEP 3



PAGE 3 OF 4

COASTERFURNITURE.COM

PRODUCT/PART DIMENSIONS



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**508462
LOVE SEAT**

ITEM : 508462



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME


15 MINUTES

PARTS IDENTIFICATION


A SEAT
1PC



B LEG
4PC



C PILLOW
2PC




ITEM : 508462


ASSEMBLY INSTRUCTIONS

STEP 1



COASTER
FINE FURNITURE




STEP 2



STEP 3



PRODUCT/PART DIMENSIONS



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**508463
CHAIR**

ITEM : 508463



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME PER UNIT:


15 MINUTES

PARTS IDENTIFICATION

A SEAT
1PC



B FRONT LEG
2PC




C REAR LEG
2PC



ITEM : 508463


ASSEMBLY INSTRUCTIONS

STEP 1





COASTER
FINE FURNITURE


STEP 2



STEP 3



PRODUCT/PART DIMENSIONS



Note: Dimension tolerance $\pm 5\%$