

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509411 SOFA

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 20 MINUTES

PARTS IDENTIFICATION

BASE 1PC

B SQUARE PILLOW 2PCS

C RECTANGLE PILLOW 2PCS


D LEG 4PCS

E MIDDLE LEG 1PC


Z HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	Q'TY
(1)	SCREW φ M5MM*30MM	 	24PCS
(2)	SHORTBOLT		8PCS
(3)	FLAT WASHER \$\phi\$ 8 MM	0	8PCS
(4)	ALLEN WRENCH		1PCS

PAGE 2 OF 4







Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509412 LOVESEAT

ASSEMBLY INSTRUCTIONS

COASTER*

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION


BASE 1PC

SQUARE PILLOW 2PCS


RECTANGLE PILLOW 1PC

Z HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	Q'TY
(1)	SCREW φ M5MM*30MM	Dimmir-	24PCS
(2)	SHORTBOLT		8PCS
(3)	FLAT WASHER \$\phi\$ 8 MM	0	8PCS
(4)	ALLEN WRENCH		1PCS







Note: Dimension tolerance ±5%