

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509421 SOFA

REVISION 0: 03/30/2022 REVISION 1: 07/19/2022

ASSEMBLY INSTRUCTIONS

COASTER®


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 20 MINUTES

PARTS IDENTIFICATION




Z HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	Q'TY
(1)	SHORT BOLT \$\phi\$12MM*34MM		16PCS
(2)	FLAT WASHER	0	16PCS
(3)	ALLEN WRENCH		1PCS







Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509422 LOVESEAT

REVISION 0: 12/10/2021 REVISION 1: 07/19/2022

ASSEMBLY INSTRUCTIONS

COASTER® FINE FURNITURE


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 20 MINUTES

PARTS IDENTIFICATION

Α



LOVESEAT

1PC

В




LEG


4PCS

Z HARDWARE PACKAGE

NO	DESCRIPTION	FIGURE	Q'TY
(1)	SHORT BOLT		16PCS
(2)	FLAT WASHER	0	16PCS
(3)	ALLEN WRENCH		1PCS







Note: Dimension tolerance ±5%