

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509647(B1&B2) Sofa

REVISION 0: 12/22/2023

PAGE 1 OF 5

COASTERFURNITURE.COM

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

## **PARTS IDENTIFICATION**

B1 (BOX 1)

A SOFA BASE



1PC

**B2 (BOX 2)** 

B LEG




4PCS

C CENTER SUPPORT LEG WITH LEVELER



1PC

D BACKREST



1PC

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

#### **HARDWARE IDENTIFICATION**


#### Z-B2 (BOX 2) - HARDWARE PACKED IS LOCATED IN 509647 (B2)


1	ALLEN WRENCH (M4 x 95mm - BLK)	1PC
2	BOLT (M6 x 50mm - BLK)	4PCS
3	FLAT WASHER (5/16" x 2mm - BLK)	4PCS
4	PLASTIC WASHER (47 x 3mm - BLK)	4PCS
5	FLAT WASHER (1/4" x 1mm - BLK)	1PC

#### **ASSEMBLY INSTRUCTIONS**

### STEP 1









#### **ASSEMBLY INSTRUCTIONS**

## STEP 3






# STEP 4 COMPLETE









Note: Dimension tolerance ±5%



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509648(B1&B2) *Loveseat* 

REVISION 0: 12/22/2023

PAGE 1 OF 5

COASTERFURNITURE.COM

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

#### **PARTS IDENTIFICATION**

B1 (BOX 1)

A LOVESEAT BASE



1PC


**B2 (BOX 2)** 

B LEG



4PCS

C BACKREST



1PC

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

#### **HARDWARE IDENTIFICATION**


#### Z-B2 (BOX 2) - HARDWARE PACKED IS LOCATED IN 509648 (B2)

1	ALLEN WRENCH (M4 x 95mm- BLK)	1PC
2	BOLT (M6 x 50mm - BLK)	4PCS
3	FLAT WASHER (5/16" x 2mm - BLK)	4PCS
4	PLASTIC WASHER (47 x 3mm - BLK)	4PCS


### **ASSEMBLY INSTRUCTIONS**

## STEP 1






## STEP 2




# ITEM: 509648(B1&B2) ASSEMBLY INSTRUCTIONS

## COASTER

## STEP 3




# STEP 4 COMPLETE









Note: Dimension tolerance ±5%