



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

509891
SOFA

ITEM: 509891

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

8 MINUTES

PARTS IDENTIFICATION

	PART NAME	FIGURE	QUANTITY
A	SOFA		1PC
B	PILLOW		2PCS
C	BACK CUSHION		2PCS
D	SEAT CUSHION		2PCS
E	LEG		4PCS

HARDWARE IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
1	BOLT 8*60mm		8PCS
2	FLAT WASHER 8*18mm		8PCS
3	ALLEN WRENCH M8		1PC
4	MIDDLE LEG		1PC

ITEM: 509891




ASSEMBLY INSTRUCTIONS


STEP 1 Turn over the item and take out the legs from zippered pouch and install the legs as pictures show




STEP 2



STEP 3 COMPLETE



ITEM: 509891



Note : Dimension tolerance $\pm 5\%$





*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

**509892
LOVESEAT**

ITEM: 509892

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.






WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME **8 MINUTES**

PARTS IDENTIFICATION

	PART NAME	FIGURE	QUANTITY
A	LOVESEAT		1PC
B	PILLOW		2PCS
C	BACK CUSHION		2PCS
D	SEAT CUSHION		2PCS
E	LEG		4PCS

HARDWARE IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
1	BOLT 8*60mm		8PCS
2	FLAT WASHER 8*18mm		8PCS
3	ALLEN WRENCH M8		1PC

ITEM: 509892




ASSEMBLY INSTRUCTIONS


STEP 1 Turn over the item and take out the legs from zippered pouch and install the legs as pictures show




STEP 2



STEP 3 COMPLETE



ITEM: 509892



Note : Dimension tolerance $\pm 5\%$





*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

509893
CHAIR

ITEM: 509893

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME **8 MINUTES**

PARTS IDENTIFICATION

	PART NAME	FIGURE	QUANTIFY
A	CHAIR		1PC
B	PILLOW		1PC
C	BACK CUSHION		1PC
D	SEAT CUSHION		1PC
E	LEG		4PCS

HARDWARE IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
1	BOLT 8*60mm		8PCS
2	FLAT WASHER 8*18mm		8PCS
3	ALLEN WRENCH M8		1PC

ITEM: 509893


ASSEMBLY INSTRUCTIONS




STEP 1 Turn over the item and take out the legs from zippered pouch and install the legs as pictures show




STEP 2



STEP 3 COMPLETE



ITEM: 509893



Note : Dimension tolerance $\pm 5\%$

