



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

511261
SOFA

REVISION 0 : 08/27/2026
REVISION 1 : 09/17/2026

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 511261



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 10 MINUTES

PARTS IDENTIFICATION

A. SOFA
BASE



1PC

B. LEG




4PCS

C. MIDDLE LEG



1PC

D. PILLOW




2PCS


ITEM: 511261
ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



ITEM: **511261**
ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$

