



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551455 ARMLESS CHAIR

ITEM: 551455

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


5 MINUTES

PARTS IDENTIFICATION


	PART NAME	FIGURE	QUANTITY
A	ARMLESS CHAIR BASE		1PC
B	LEG		4PCS
C	PILLOW		2PCS

ITEM: 551455


ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2




STEP 3





ITEM: 551455



ASSEMBLY INSTRUCTIONS
STEP 4



STEP 5
COMPLETE



ITEM: 551455



Note : Dimension tolerance $\pm 5\%$

