

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

ARMLESS CHAIR

PAGE 1 OF 5

COASTERFURNITURE.COM

REVISION 0: 11/12/2021 REVISION 1: 08/02/2022 REVISION 2: 07/28/2025

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 5 MINUTES

	PART NAME	FIGURE	QUANTITY
A	ARMLESS CHAIR		1PC
В	LEG		4PCS

ASSEMBLY INSTRUCTIONS







COASTERFURNITURE.COM


PAGE 3 OF 5











Note:Dimension tolerance <u>+ 5</u>%





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0: 11/22/2021 REVISION 1: 08/02/2022

551621-3 6PC SECTIONAL

PAGE 1 OF 9

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

	PART NAME	FIGURE	QUANTITY
A	ARMLESS CHAIR		1PC
В	LEG		4PCS

ITEM: **551621**ASSEMBLY INSTRUCTIONS





COASTERFURNITURE.COM

PAGE 3 OF 9

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

	PART NAME	FIGURE	QUANTITY
A	CORNER		1PC
В	LEG		4PCS





ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 5 MINUTES

	PART NAME	FIGURE	QUANTITY
A	OTTOMAN		1PC
В	LEG		4PCS

ITEM: **551623**ASSEMBLY INSTRUCTIONS






COASTERFURNITURE.COM


ITEM: 551621-3





ITEM: 551621-3





Note:Dimension tolerance + 5%





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551622 CORNER

REVISION 0: 11/12/2021 REVISION 1: 08/02/2022 REVISION 2: 07/28/2025

PAGE 1 OF 5

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME


5 MINUTES

	PART NAME	FIGURE	QUANTITY
A	CORNER		1PC
В	LEG		4PCS

















Note:Dimension tolerance + 5%





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

551623 OTTOMAN

REVISION 0: 11/12/2021 REVISION 1: 08/02/2022 REVISION 2: 07/28/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!




- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 5 MINUTES


	PART NAME	FIGURE	QUANTITY
A	OTTOMAN		1PC
В	LEG		4PCS











Note:Dimension tolerance <u>+</u>5%

