



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



600370
Sectional

REVISION 0: 05/17/2019
REVISION 1: 01/09/2020
REVISION 2: 09/18/2020
REVISION 3: 08/23/2023

PAGE 1 OF 12

COASTERFURNITURE.COM

ITEM: 600370B1

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.


2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING !

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME PER UNIT:

15MINUTES

PARTS IDENTIFICATION

A

LOVESEAT BASE 1PC

B

LOVESEAT LEFT BACK 1PC

C

LOVESEAT RIGHT BACK 1PC

D

LEFT POWER CABLE 1PC

E


CONSOLE BACK 1PC

ITEM: 600370B1


ASSEMBLY INSTRUCTIONS




STEP 1





STEP 2



STEP 3



STEP 4




ITEM: 600370B2

ASSEMBLY INSTRUCTIONS



PARTS IDENTIFICATION

F




WEGDE BASE 1PC

G



WEDGE LEFT BACK 1PC

H




WEDGE RIGHT BACK 1PC

ITEM: 600370B2



ASSEMBLY INSTRUCTIONS



STEP 1



STEP2




ITEM: 600370B3

ASSEMBLY INSTRUCTIONS




PARTS IDENTIFICATION

I



RAF BASE 1PC

J



RAF BACK 1PC

K




RIGHT POWER CABLE 1PC

ITEM: 600370B3



ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: 600370AC

ASSEMBLY INSTRUCTIONS




PARTS IDENTIFICATION

L



CHAIR BASE 1PC

M




CHAIR BACK 1PC

ITEM: 600370AC

ASSEMBLY INSTRUCTIONS



STEP 1




ITEM: 600370

ASSEMBLY INSTRUCTIONS



PARTS IDENTIFICATION

600370B1



LAF POWER LOVESEAT 1PC

600370B2



WEDGE 1PC

600370AC




ARMLESS CHAIR 1PC

600370B3





RAF POWER RECLINER CHAIR 1PC

STEP 1



STEP 2





Note : Dimension tolerance $\pm 5\%$

COASTER® 600370AC

Fine Furniture

ARMLESS CHAIR

ASSEMBLY INSTRUCTION COASTER FINE FURNITURE



www.coastercompany.com


ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:



- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠ WARNING !



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.

ASSEMBLY TIME PER UNIT: **2 MINUTES**

PARTS IDENTIFICATION

ACHAIR BASE 1PC**B**CHAIR BACK 1PC

STEP 1



COASTER® **600370B1**
Fine Furniture **LAF POWER LOVESEAT**

ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE



www.coastercompany.com

ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



⚠ WARNING !

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME PER UNIT: 4 MINUTES


PARTS IDENTIFICATION

ALOVESEAT BASE 1PCBLOVESEAT LEFT BACK 1PCCLOVESEAT RIGHT BACK 1PCDPOWER BOX 1PCFCONSOLE BACK 1PC


STEP 1



STEP 2



STEP 3






STEP 4



BOTTOM

STEP 5



COASTER[®]
Fine Furniture

600370B2

WEDGE

**ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE**



www.coastercompany.com

ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.


⚠ WARNING !

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME PER UNIT: 3 MINUTES


PARTS IDENTIFICATION

A

BASE

1PCB


LEFT BACK

1PCC




RIGHT BACK

1PC

STEP 1



STEP 2



COASTER
Fine Furniture

600370B3

RAF POWER RECLINER

**ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE**



www.coastercompany.com


ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠ WARNING !


- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME PER UNIT:

3 MINUTES


PARTS IDENTIFICATION

A

RAF BASE

1PCB


RAF BACK

1PCC

POWER BOX

1PC

STEP 1



STEP2



BOTTOM

