



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

600570RLPPP
RAF TRI POWER LOVESEAT

ITEM :600570RLPPP
ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION

A RIGHT EAR



1 PC

B RIGHT BACK



1 PC

C LEFT BACK



1 PC

D BASE




1 PC

E PLUG-IN POWER SUPPLY




1 PC


STEP 1




STEP 2




STEP 3



STEP 4




STEP 5
COMPLETE




STEP 6


OPTION1:



OPTION2:




STEP 7




Please follow below steps to install the 9V batteries when there is no power to operate the motion sofa.(Any model of 9V battery is applicable)

STEP 1


Open the marked battery door on the backup battery box.

**STEP 2**

Install two 9V batteries in the backup battery box.(batteries are not included)


**STEP 3**



Push the batteries in.

**STEP 4**

Close the box door.

Notice: Please don't keep the battery in the box when the power motion sofa is under daily use with power supply.





Note: Dimension tolerance +5%