



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

609530AC
ARMLESS CHAIR

REVISION 0: 8/28/2024
REVISION 1: 6/12/2025

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: **609530AC**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A



BASE

1PC


B



LEG

4PCS

C



BACK CUSHION


1PC

ITEM: **609530AC**




ASSEMBLY INSTRUCTIONS


STEP 1





STEP 2




STEP 3 COMPLETE



ITEM:609530AC



ITEM:609530AC



Note:Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

609530LRP
LAF POWER RECLINER

REVISION 0: 8/28/2024
REVISION 1: 6/12/2025

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: **609530LRP**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!







1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION


A		BASE	1PC
B		LEG	4PCS
C		TRANSFORMER/POWER CORD	1PC
D		ARM PILLOW	1PC
E		RECLINER BACK	1PC
F		BACK CUSHION	1PC

ITEM: **609530LRP**




ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2






STEP 3






STEP 4 **COMPLETE**



ITEM:609530LRP



ITEM:609530LRP



Note:Dimension tolerance \pm 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

609530RRP
RAF POWER RECLINER

REVISION 0: 8/28/2024
REVISION 1: 6/12/2025

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: **609530RRP**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!







1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION


A		BASE	1PC
B		LEG	4PCS
C		TRANSFORMER/POWER CORD	1PC
D		ARM PILLOW	1PC
E		RECLINER BACK	1PC
F		BACK CUSHION	1PC

ITEM: **609530RRP**




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2





STEP 3






STEP 4 **COMPLETE**



ITEM:609530RRP



ITEM:609530RRP



Note:Dimension tolerance $\pm 5\%$